



B055



| Ausgabe Issue 2002- 2 | | Bild Nr Picture No B055 | | HANSEATIC 45 B | | HANSEATIC 45 B | | Seite Page 10 | |
|-----------------------------|-----------------|-------------------------------|------------|----------------|------------------------|------------------------------|-----------------------------|---------------------|---|
| Pos. Fig. | Anzahl/Quantity | | | | Artikel Nr. Part No | Bezeichnung | Description | Satz Kit | Anmerkung Notes |
| | 321 737 | 321 749 | 321 750 | 361 737 | | | | | |
| X | 1 | 1 | 1 | 1 | 1117-3262-05 | Chassie | Chassis | | |
| | 2 | 2 | 2 | 2 | 1117-3009-01 | Radplatte | Wheel plate | | |
| | 3 | 2 | 2 | 2 | 1117-3010-01 | Radplatte | Wheel plate | | |
| | 4 | 1 | 1 | 1 | 1117-3011-01 | Radachse | Wheel axle | | |
| | 5 | 2 | 2 | 2 | 1111-3238-01 | Rad | Wheel | | |
| | 6 | 2 | 2 | 2 | 1117-3225-02 | Nabenkapsel- weiß | Hub cap- white | | |
| | 7 | 1 | 1 | 1 | 1117-3007-01 | Leitschiene- vordere | Baffle- front | | |
| | 8 | 4 | 4 | 4 | 1117-3223-01 | Ansatzbolzen | Shoulder bolt | | |
| | 9 | 2 | 2 | 2 | 1117-3224-02 | Nabenkapsel- weiß | Hub cap- white | | |
| | 10 | 2 | 2 | 2 | 1117-1161-01 | Radschutz | Wheel protection | | |
| | 11 | 1 | 1 | 1 | 1117-3008-01 | Leitschiene- hintere | Baffle- rear | | |
| | 12 | 14 | 14 | 14 | 9836-9516-12 | Schraube | Screw | | |
| | 13 | 1 | 1 | 1 | 1117-1156-02 | Klappe- schwarz | Rear flap- black | | |
| | 14 | 1 | 1 | 1 | 1117-1143-01 | Achse | Shaft | | |
| | 15 | 1 | 1 | 1 | 1117-1126-01 | Feder | Spring- rear flap | | |
| | 16 | 1 | 1 | 1 | 1117-1155-02 | Klapphalterung- schw. | Flap holder- black | | |
| | 17 | 1 | 1 | 1 | 1117-1135-02 | • Deckel- schwarz | • Cover- black | | |
| | 18 | 1 | 1 | 1 | 9987-5251-12 | Schraube | Screw | | |
| | 19 | 1 | 1 | 1 | 1117-1065-01 | Tellerfeder | Spring washer | | |
| | 20 | 2 | 2 | 2 | 1111-3163-01 | Rad | Wheel | | |
| | 21 | 8 | 8 | 8 | 1117-3012-01 | Lagerbuchse | Wheel bush | | |
| | 22 | 4 | 4 | 4 | 1117-1364-01 | Schraube | Screw | | |
| | 23 | 1 | 1 | 1 | 9600-0014-00 | Keil | Key | | |
| X | 24 | 1 | 1 | 2 | 1111-9723-01 | Messer | Blade | | |
| | 25 | 4 | 4 | 4 | 1117-1131-01 | Mutter | Nut | | |
| | 26 | 6 | 6 | 6 | 9699-0028-02 | Scheibe | Flat washer | | |
| | 27 | 2 | 2 | 2 | 9898-0845-12 | Schraube | Screw | | |
| | 28 | 1 | 1 | 1 | 1117-3030-01 | Montagesatz | Assy kit | | |
| | 29 | 4 | 4 | 4 | 9579-0008-00 | Kabelhalter | Cable holder | | |
| | 30 | 2 | 2 | 2 | 1117-3194-01 | Verriegelungsrad | Locking knob | | |
| | 31 | 5 | 5 | 5 | 9799-0831-02 | Mutter | Nut | | |
| | 32 | 1 | 1 | 1 | 1117-1149-01 | Führungsholm- Untert. | Handle- lower part | | |
| | 33 | 1 | 1 | 1 | 1117-1221-01 | Führungsholm- Obert. | Handle- upper part | | |
| | 34 | 1 | 1 | 1 | 1117-1355-01 | Schlüssel | Socket wrench | | |
| | 35 | 1 | 1 | 1 | 1117-1183-01 | Motorbremsdraht | Engine brake cable | | |
| X | 35 | | | | 1117-3273-01 | Motorbremsdraht | Engine brake cable | | Briggs & Stratton Tecumseh Inkl. 17 |
| | 36 | 1 | 1 | 1 | 1117-1157-02 | Behälterdeckel- schwar. | Grassbag cover- black | | |
| | 37 | 1 | 1 | 1 | 1117-1218-01 | Behälter- Unterteil | Lower grass bag | | |
| | 38 | 1 | 1 | 1 | 1117-1148-01 | Deckel | Cap | | |
| | 39 | 1 | 1 | 1 | 9948-0640-16 | Schraube | Screw | | |
| | 40 | 1 | 1 | 1 | 9699-0025-02 | Scheibe | Washer | | |
| | 41 | 1 | 1 | 1 | 9595-0258-00 | Spannstift | Locating pin | | |
| | 42 | 1 | 1 | 1 | 1111-9719-01 | Messerhalterung | Blade holder | | |
| | 43 | 1 | 1 | 1 | 1117-3221-01 | Regulierbügel | OPC lever | | |
| | 44 | 3 | 3 | 3 | 9997-0830-16 | Schraube | Screw | | |
| | 45 | 3 | 3 | 3 | 9678-0009-02 | Schloßscheibe | Lock washer | | |
| | 46 | 1 | 1 | 1 | 1111-2927-01 | Batteriehalter | Battery holder | | |
| | 47 | 1 | 1 | 1 | 1117-1116-01 | Schnurhalter | Rope holder | | |
| | 48 | 1 | 1 | 1 | 9799-0631-02 | Mutter | Nut | | |
| | 49 | 1 | 1 | 1 | 1117-1119-01 | Propfen | Cap | | |