

Genuine Spare Parts

www.stiga.com

CABLE LAYER NT 60 Model Year 2012

includes:


26-2911-11CABLE LAYER NT 60

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


STIGA®



60400


Utgåva Issue		Bildnr Picture No		NT 60 BORR		NT60 DRILL		Sida Page	
2012- 11		01						2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2911								
1	1				1126-8109-01	Skruv	Screw		
2	1				1126-8011-01	Bricka	Washer		
3	1				1126-8010-01	Remskiva	Stamp pulley		
4	1				1126-8034-01	Distans	Spacer		
5	1				1126-8053-01	Bricka	Washer		
6	1				1126-8009-01	Kullager	Ball bearing		
7	1				1126-8026-01	Stöd	Support		
8	2				9997-0660-01	Skruv	Screw		
9	4				9739-0631-22	Mutter	Nut		
10	1				1126-8036-01	Fjäder	Spring		
11	1				1126-8004-01	Spårring	Brenzing ring		
12	1				1126-8022-01	Bromsplatta	Brake plate		
13	1				9997-0516-16	Skruv	Screw		
14	1				1126-8012-01	Broms	Brake		
15	1				1126-8023-01	Distans	Spacer		
16	4				9739-0831-22	Mutter	Nut		
17	1				9699-0090-02	Bricka	Washer		
18	1				9997-0840-12	Skruv	Screw		
19	1				9997-0616-16	Skruv	Screw		
20	1				9997-0820-16	Skruv	Screw		
21	1				1126-8033-01	Vingskruv	Knob		
22	1				9997-0810-12	Skruv	Screw		
23	1				1126-8032-01	Axel	Shaft		
24	1				1126-8024-01	Hjul kpl.	Wheel cpl.		
25	1				1126-8003-01	Segersäkring	Lock ring		
26	1				1126-8002-01	Segersäkring	Lock ring		
27	1				1126-8008-01	Kullager	Ball bearing		
28	1				1126-8021-01	Axel	Shaft		
29	1				1126-8030-01	Kula	Ball		
30	1				1126-8054-01	Bricka	Washer		
31	1				1126-8031-01	Fjäder	Spring		
32	1				1126-8104-01	Skruv	Screw		
33	1				1126-8020-01	Fäste	Bracket		
34A	1				1126-8018-01	Borr kit	Drill kit		
34B	1				1126-8019-01	Borr kit	Drill kit		
35	1				9997-0835-16	Skruv	Screw		
36	1				1126-8006-01	Bricka	Washer		
37	1				1126-8017-01	Distans	Spacer		
38	1				1126-8015-01	Reglagestång	Control rod		
39	1				9747-0531-02	Mutter	Nut		
40	1				1126-8035-01	Fjäder	Spring		
41	1				1126-8005-01	Starlock	Starlock		
42	1				1126-8016-01	Fäste	Bracket		
43	1				1126-8016-01	Distans	Spacer		
44	2				1126-8000-01	Segersäkring	Lock ring		
45	1				1126-8007-01	Kullager	Ball bearing		
46	1				1126-8014-01	Distans	Spacer		
47	1				9699-0090-02	Bricka	Washer		
48	1				9997-0835-12	Skruv	Screw		
49	1				9747-0531-02	Mutter	Nut		
50	1				1126-8027-01	Stöd	Support		
51	1				1126-8029-01	Handtag	Handle		
52	1				1126-8025-01	Fäste	Bracket		

3 Drills
3 Drills (hardened)



60401

Utgåva Issue		Bildnr Picture No		NT 60 MOTOR		NT 60 ENGINE		Sida Page	
2012- 11		02						4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2911								
1	1				1126-8107-01	Motor	Engine		Honda
2	7				9739-0831-22	Mutter	Nut		
3	4				9699-0090-02	Bricka	Washer		
4	5				9997-0835-12	Skruv	Screw		
5	1				1126-8057-01	Kil	Key		
6	2				1126-8105-01	Spännstift	Pin		
7	1				1126-8088-01	Rem	Belt		
8	1				1126-8063-01	Remskiva	Pulley		
9	3					Bricka	Washer		
10	1					Bricka	Washer		
11	1				1126-8108-01	Skruv	Screw		
12	1				1126-8084-01	Nivåkonsol	Rack		
13	1				1126-8089-01	Distans	Spacer		
14	1				9997-0820-16	Skruv	Screw		
15	1				1126-8064-01	Remskiva	Pulley		
16	1				1126-8065-01	Rem	Belt		
17	2				1126-8106-01	Spännstift	Pin		
18	1				1126-8058-01	Spännstift	Pin		
19	1				1126-8038-01	Kedjehjul	Pinion		
20	1				1126-8056-01	Kil	Key		
21	1				1126-8074-01	Väckellåda	Gear box		
22	1				1126-8078-01	Konsol	Gear box support		
23	4				9747-0531-02	Mutter	Nut		
24	1				1126-8055-01	Kullager	Ball bearing		
25	2				9997-0818-16	Skruv	Screw		
26	3				1126-8001-01	Segersäkring	Lock ring		
27	3				1126-8053-01	Bricka	Washer		
28	2				1126-8041-01	Lager	Bearing		
29A	1				1126-8043-01	Hjul- Hö	Wheel- RH		
29B	1				1126-8044-01	Hjul- Vä	Wheel- LH		
30A	1				1126-8080-01	Hjulaxel- Hö	Wheel shaft- RH		
30B	1				1126-8081-01	Hjulaxel- Vä	Wheel shaft- LH		
31	1				1126-8059-01	O- ring	O- ring		
32	1				1126-8067-01	Hjulskydd	Wheel cover		
33	1				1126-8103-01	Låsspring	Locking ring		
34	1				1126-8079-01	Drevaxel	Shaft		
35	1				9997-0635-12	Skruv	Screw		
36	1				9699-0060-02	Bricka	Washer		
37	1				1136-8069-01	Ram	Frame		
38	1				1126-8068-01	Kåpa- bakre	Cover- rear		
39	1				1129-8071-01	Kåpa- främre	Cover- front		
40	1				1126-8091-01	Dekal kit	Label kit		
41	1				1126-8090-01	Dekal CE	Label CE		
42	11				1126-8110-01	Skuv	Screw		
43	1				1126-8037-01	Kedjelänk	Link		



60402

Utgåva Issue 2012- 11		Bildnr Picture No 03		NT 60 HANDREGLAGE		NT 60 HAND CONTROLS		Sida Page 6	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2911								
1	1				1126-8092-01	Handtag	Handle		
2	3				9997-0620-16	Skruv	Screw		
3	4				9747-0631-02	Mutter	Nut		
4	6				9799-0631-22	Mutter	Nut		
5	3				1126-8060-01	Gångskruv.....	Register		
6	1				1126-8085-01	Wire	Cable		
7	4				1126-8062-01	Bussning.....	Bush.....		
8	2				1126-8061-01	Fjäder.....	Spring		
9	1				1126-8102-01	Klämma.....	Clamp.....		
10	1				1126-8076-01	Styre- övre	Handlebar- upper.....		
11	1				1126-8096-01	Justerratt	Adjust knob		
12	2				1126-8095-01	Handtag	Handle		
13	1				1126-8042-01	Gasreglage kpl	Throttle cpl.		
14	1				9997-0640-12	Skruv	Screw		
15	1				9699-0060-02	Bricka.....	Washer		
16	1				1126-8097-01	Ändavslut.....	Cap		
17	1				1126-8094-01	Handtag- Hö.....	Handle- RH.....		
18	1				1126-8087-01	Wire	Cable		
19	1				1126-8094-01	Handtag- Vä	Handle- LH.....		
20	1				1126-8086-01	Wire	Cable		
21	1				1126-8040-01	Gummibussning.....	Rubber bush.....		
22	1				1126-8066-01	Klämma.....	Clamp.....		
23	1				1126-8039-01	Justerratt	Adjust knob		
24	1				1126-8077-01	Styre- nedre	Handle- lower		
25	2				9997-0850-12	Skruv	Screw		
26	2				9699-0056-02	Bricka.....	Washer		
27	4				1126-8045-01	Lager.....	Bearing		
28	2				1126-8101-01	Bussning.....	Bush.....		
29	2				1126-8110-01	Skruv	Screw		
30	2				9739-0631-22	Mutter	Nut		
31	1				1126-8075-01	Stöd	Support		
32	1				1126-8047-01	Fjäder.....	Spring		
33	1				1126-8046-01	Borraxel	Drill shaft.....		
34	1				1126-8099-01	Låsning	Locking cap		
35	2				1126-8073-01	Bussning.....	Bush.....		
36	1				1126-8098-01	Handtag	Handle		
37	1				9997-0820-16	Skruv	Screw		
38	1				1126-8072-01	Fäste	Plate		
39	1				1126-8100-01	Justerratt	Adjust knob		
40	1				1126-8083-01	Rulle	Reel		
41	1				1126-8070-01	Fäste	Plate		
42	1				9997-0516-16	Skruv	Screw		
43	1				1126-8082-01	Rullfäste.....	Cable bracket.....		
44	1				9997-0820-16	Skruv	Screw		