



## Section: COLLECTOR 46-460 CHASSIS

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			1215				
			1115 1514				
	1111 1411	1415	1515				
1	1	1	1	1111-1423-01	Blade bar assy		
2	1	1	1	1111-9048-01	.Blade kit	K-FÖRP	
3	2	2	2	9997-0816-16	..Screw		
4	2	2	2	9747-0831-02	..Lock nut		
6	1	1	1	9987-5232-16	Bolt		
7	1	1	1	9696-0011-01	Washer		
10	1	1	1	1111-9054-01	Blade holder assy		
11	1	1	1	9600-0014-00	.Key		
12	4	4	2	1111-0545-00	Shoulder bolt		
13	4	4	2	9694-0001-00	Washer		
14	4	4	2	9699-0069-02	Flat washer		
15	4	4	2	1111-1268-01	Axle mounting		
16	4	4	2	1111-1337-01	Control lever		
17	4	4		1111-2656-01	Wheel		
18	4	4	2	1111-0497-00	Hole plate		
19	4	4	2	1111-2057-02	Bushing		
20	1	1	1	1111-9042-01	Wheel lock kit		
20	4	4	2	9675-0017-02	.Lock washer		
21	4	4	2	9595-0182-00	Slotted pin		
22	1	1	1	1111-2526-01	Wheel axle		
23	4	4	2	1111-1335-01	Hub cap		
24	1	1		1111-2525-01	Rear axle		
25	4	4	2	9739-0831-22	Nut		
26	3	3	2	9997-0835-12	Screw	35 mm	
26			1	9997-0860-16	Screw	60 mm	
27	3	3	3	9683-0030-02	Lock washer		
28	3	3	3	9799-0831-02	Nut		
32			1	1111-3062-01	Eyelink		
34	4	4	4	9997-0812-16	Screw		
35	1		1	1111-9030-02	Handle bolt kit		
35	2	2	2	1111-0035-01	.Locking knob		
36	2	2	2	9699-0025-02	.Washer		
37	2	2	2	9899-3545-12	.Screw		
38	1	1	1	1111-2018-01	Cable holder		
39	4	4	4	9716-0831-02	Nut		
40	1	1	1	1111-2165-01	Handlebar-lower par		
41	1		1	1111-2005-01	Handlebar-upper par		
41			1	1111-2520-01	Handlebar-upper par		
41		1		1111-1969-01	Handlebar-upper par		
42	1	1	1	9836-9216-12	Screw		
43			1	9403-0043-70	Plug		
45	1		1	1111-2546-02	Side guard-L.H.	1111, 1115	
45	1			1111-2556-02	Side guard-R.H.	1111-, 1115	
46	1	1	1	1111-2490-01	Chassie-yellow		
47	1	1	1	1111-1614-02	Flap-yellow		
48			1	1111-2611-05	Throttle control	1514	
48	1	1		1111-2365-06	Gas control		
48			1	1111-2368-04	Gas control		
48			1	1111-2612-02	Gas control	1215", 1515	
50	2	2	2	9948-0645-16	Screw		
51	2	2	2	9747-0631-02	Lock nut		
53	2	2	2	9675-0012-02	Locking washer		
54	1	1	1	1111-1532-01	Pivot rod		
55	1	1	1	1111-1616-01	Spring-L.H.		
56	1	1	1	1111-1616-02	Spring-R.H.		
57			4	1111-2784-01	Wheel assy		
58			1	1111-9047-01	.Ball bearing kit		
59			2	1111-1184-01	..Bearing cone		
60			4	1111-1138-01	Spring		
61	1			1111-2487-01	Front cover-black		
61	1	1	1	1111-2487-02	Front cover-yellow		
62	4	4	4	9836-9516-12	Screw		
64	2	2	2	1111-1619-01	Grass catcher half		
65	2	2	2	1111-1635-01	Handle		
67			1	9579-0008-00	Cable holder		
69		1		1111-1925-01	Protection		

