



Section: 524-827-827T AUGER ASSY

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		2825	2834	2835			
1	1			1812-1161-01		Chute extension	
2	1	1	1	1812-1220-01		Flange	
3	1	1	1	1812-1180-01		Chute ring	
4	3	3	3	1812-1198-01		Retainer	
5	2	2	2	1812-0388-01		Screw	
6	6	6	6	1812-0389-01		Locking nut	
7	30	30	30	9899-3622-16		Screw	
8	31	29	29	9699-0028-02		Flat washer	
9	33	32	32	9683-0030-02		Lock washer	
10	33	32	32	9795-3631-02		Nut	
11	1			1812-0662-01		Chute deflector	
12	2			1812-0667-01		Plastic washer	
13	1			1812-1108-01		Knob	
14	1			9699-0069-02		Flat washer	
15	1			1812-0273-01		Screw	
16	1			9988-3619-16		Screw	
17	1	1	1	1812-1162-01		Return spring	
18	1			9743-3621-32		Nut	
19	1	1	1	1812-1244-01		Brake pad	
20	1	1	1	1812-0401-01		Pin	
21	1	1	1	1812-1229-01		Ball bearing	
22	1	1	1	1812-1260-01		Auger pulley	
23	1	1	1	1812-1167-01		Key	
24	1	1	1	1812-1250-01		Retainer bearing	
25	3	3	3	9988-3616-16		Screw	
26	4	4	4	1812-0387-01		Screw	
27	2	2	2	1812-1158-01		Height adjuster	
28		1		1812-1270-01		Auger housing	
28	1			1812-1271-01		Auger housing	
28			1	1812-1282-01		Auger housing	
29	1			1812-1182-01		Scraper bar	
29		1	1	1812-1258-01		Scraper bar	
30	2	2	2	1812-0347-01		Bearing	
31	2	2	2	1812-0397-01		Spacer	
32	1			1812-1273-01		Auger-R.H.	
32		1	1	1812-1275-01		Auger-R.H.	
33	1			1812-1272-01		Auger-L.H.	
33		1	1	1812-1274-01		Auger-L.H.	
34	1	1	1	1812-9005-01		Shear bolt kit	
36	2	2	2	1812-0531-01		.Spacer	
37	1			1812-1277-01		Gear box assy	
37		1	1	1812-1278-01		Gear box assy	
38	1	1	1	1812-0868-01		Side plate-L.H.	
39	1	1	1	1812-0869-01		Side plate-R.H.	
40	2			1812-1163-01		Plastic washer	
41	1	1	1	9699-0038-02		Flat washer	
42	1	1	1	9743-5421-32		Nut	
43	1	1	1	1812-1263-01		Spacer	
44		1		1812-1235-01		Rod brake arm	
44	1		1	1812-1234-01		Rod brake arm	