



Section: VILLA TRANSMISSION ENGINE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		2841	2842				
	2812	2855	2858				
1	4	4	4	9739-0831-22	Nut		
2	1	1	1	9600-0050-00	Key		
3	1	1	1	1134-0269-00	Pedal rubber		
4	1	1	1	1134-2123-02	Clutch pedal		
7	1	1	1	1134-1927-01	Bearing		
15	1	1	1	1134-1949-01	Spring		
20	1	1	1	1134-1631-02	Tensioner arm		
21	1	1	1	9696-0013-01	Bowed washer		
22	1	1	1	9699-0037-02	Washer		
23	1	1	1	1134-0240-00	Shoulder screw		
24	4	4	4	9997-0840-16	Screw		
25	1	1	1	1134-0139-01	Belt guide		
26	1	1	1	1134-1849-01	Belt pulley		
27	1	1	1	1134-9008-01	V-belt	=9585-0050-00	
31	1	1	1	9650-0016-04	Lock ring		
32	1	1	1	9997-1450-16	Puller-belt pulley	Tillbehör/Accessory	
32	1	1	1	1134-1633-01	Engine belt pulley		
35	1	1	1	1134-9027-01	Tension roller		
37	1	1	1	9739-1031-22	Nut		
39	1	1	1	9987-5338-12	Screw		
40	4	4	4	9699-0090-02	Flat washer		
42	1	1	1	1134-1364-02	Spacer ring		
43	1	1	1	9959-0825-16	Screw		
44	1	1	1	1134-1795-01	Belt stirrup		
47	1	1	1	9997-1030-16	Screw		
48	4	4	4	9739-0631-22	Nut		
49	2	2	2	9898-0635-12	Screw		
50	1	1	1	1134-1931-01	Clutch rod		
51	1	1	1	1134-1889-01	Eyebolt		
52	1	1	1	9747-0631-02	Lock nut		
53	2	2	2	9799-0831-02	Nut		
54	1	1	1	9595-0160-00	Locating pin		
59	1	1	1	9600-0250-00	Key		
60	1	1	1	1134-1594-01	Panel		
63	2	2	2	9959-0612-16	Screw		
64	2	2	2	9849-8009-16	Screw		
65	1	1	1	1134-1975-01	Gas control		
66	1	1	1	9403-0035-10	Handle		
68			1	1134-2350-01	Exhaust pipe		
69			1	1134-0433-00	Muffler gasket		
70			2	9988-3651-12	Screw		
71			1	1134-3245-02	Muffler		
72			1	9578-0011-00	Clamp		
73			1	1134-2462-01	Lock		
74			2	1134-1565-01	Spacer		
75			1	1134-2354-01	Heat guard		
76			2	9997-0612-16	Screw		
83			1	9959-0820-16	Screw		
84			1	1134-2352-02	Tow bar		
87			1	1134-2394-01	Heat guard		
88			2	9739-0831-22	Nut		
92			1	1134-3582-01	Fuel tank	2858-19,2858-99	
93			1	1134-2877-02	Fuel tank cap	2858-19,2858-99	
94			1	1134-3586-01	Strap-short	2858-19,2858-99	
95			1	1134-3587-01	Strap-long	2858-19,2858-99	
96			2	9948-0630-16	Screw	2858-19,2858-99	
97			2	9747-0631-02	Lock nut	2858-19,2858-99	
98			1	1134-3225-01	Grommet	2858-19,2858-99	
99			1	1134-3224-01	Fuel shut-off valve	2858-19,2858-99	