



Section: MULTICLIP S-SE TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	3615	3619				
1	1	1	1111-2910-01		Wheel mounting-RH	
2	1	1	1111-2911-01		Wheel mounting-LH	
3	2	2	1111-2909-01		.Bearing	
4	1	1	1111-2549-01		.Plastic knob	
5	2	2	1111-1456-01		Washer	
6	2	2	1111-2561-01		Cover plate	
7	2	2	1111-2382-01		Pin	
8	2	2	1111-2635-01		Gear wheel	
9	2	2	9699-0100-02		Washer	
10	2	2	9946-0612-16		Screw	
16	2	2	9699-0037-02		Washer	
17	2	2	1111-1138-01		Spring	
18	2	2	1111-2665-01		Wheel assy	
19	1	1	1111-9047-01		.Ball bearing kit	
20	2	2	1111-1184-01		.Bearing cone	
21	2	2	9699-0100-02		Washer	
22	2	2	9946-0612-16		Screw	
23	2	2	1111-2664-01		Hub cap	
24	2	2	1111-2676-01		Wheel cup	
30	1	1	1111-2633-01		Front cover-yellow	
31	1	1	9943-0530-16		Screw	30 mm
32	2	2	9943-0540-16		Screw	40 mm
33	2	2	9739-0531-22		Nut	
40	1	1	1111-9060-01		Drive belt	
41	1	1	1111-2127-01		Belt pulley	
42	1	1	9911-0612-16		Set screw	
43	1	1	1111-2565-01		Belt pulley	
44	2	2	9659-0050-04		Lock ring	
45	1	1	1111-2641-01		Transmission assy	Se grupp 29
46	1	1	F000-3475-00		.Key	
47	1	1	1111-2636-01		Cable holder	
48	1	1	9943-0510-16		Screw	
49	1	1	1134-1023-00		Spring	
50	1	1	1111-2621-01		Spring stop	
55		2	9836-9520-12		Screw	
56		1	9400-0186-00		Starting switch ass	
57		1	1134-2848-01		.Ignition key	
58		1	1111-2707-01		Housing	
59		1	1111-2705-01		Cover	
60		1	1111-2562-02		Harness	
65	1	1	1111-2965-03		Clutch control	
66	2	2	9747-0631-02		Lock nut	
67	2	2	9948-0655-16		Screw	
68	1	1	9836-9512-12		Screw	
69		2	9865-0580-16		Screw	
70		2	9693-0004-02		Washer	
71		1	1111-2733-01		Cover	
72		1	9400-0218-00		Battery	
73		1	9400-0219-00		Charger	
74		2	9739-0531-22		Nut	
75		1	1111-2018-01		Cable holder	
76		1	9836-9216-12		Screw	
77	1	1	9579-0008-00		Cable holder	
78	1	1	1111-1987-02		Control knob-black	