



## Section: SILENT 42 ELECTRIC CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2872					
1	1	1111-2739-01	Blade bar assy			
2	1	1111-9048-01	.Blade kit			
3	2	9997-0816-16	..Screw			
4	2	9747-0831-02	..Lock nut			
5	1	1111-1753-01	Ventilator			
6	1	1111-2679-03	Blade bolt			
9	1	1111-1275-01	Washer			
10	1	1111-2689-01	Blade holder			
11	1	9600-0132-00	Flat key			
12	1	9500-1700-00	Electric motor			
13	3	9997-0825-16	Screw			
14	3	9699-0078-02	Washer			
15	1	9400-0227-00	Capacitor			
16	1	9579-0003-00	Cable holder			
17	6	1111-1959-02	Plastic washer			
18	1	1111-2215-01	Engine housing			
19	3	9836-9512-12	Screw			
20	1	9579-0007-00	Cord restrainer			
21	2	9849-7819-16	Screw			
22	3	9747-0831-02	Lock nut			
23	1	1111-2214-01	Attachment ring			
24	1	1111-1749-01	Cover			
25	1	1111-2690-01	Chassis			
26	1	1111-1764-02	Flap attachment			
27	7	9836-9512-12	Screw			
28	1	1111-1748-01	Guide plate			
29	3	9848-8013-16	Screw			
30	1	1111-1805-01	Rod			
31	2	9672-0002-02	Lock washer			
33	1	1111-2324-01	Spring			
34	1	1111-1747-02	Flap-yellow			
36	1	1111-1635-01	Handle			
37	1	1111-2047-01	Upper part collecto			
38	1	1111-1813-01	Mounting frame			
39	2	1111-2045-01	Holder			
40	4	9836-9512-12	Screw			
41	2	9836-9516-12	Screw			
42	1	1111-2043-02	Collecting bag			
43	1	1111-2044-01	Wire clamp			
52	1	1111-2977-02	Motor cover-green			
53	3	9836-9512-12	Screw			
55	1	1111-1419-01	Blade wrench			
58	1	9400-0233-00	Cable connection			
59	1	9836-9216-12	Screw			
60	2	1111-1958-01	Seal			
61	4	9699-0078-02	Washer			
62	4	9997-0812-16	Screw			
63	1	1111-2386-01	Seal			
99	1	1111-2893-09	Decal kit			