



Section: TURBO 530S-530SE HANDLEBAR ELECTRICAL SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	8518	8621				
1	1	1	1111-2435-01		Front axle	
2	1	1	1111-2463-01		Spring	
3	2	2	1111-1504-01		Retainer	
4	2	2	9947-0616-16		Screw	
12	1	1	1111-2461-01		Tension rod	
13	2	2	9675-0012-02		Locking washer	
15	2	2	9946-0612-16		Screw	
16	2	2	9699-0037-02		Washer	
18	2	2	1111-2183-01		Spring	
19	2	2	1111-2141-01		Cover plate	
20	2	2	1111-2346-01		Wheel w/o bearing	
21	4	4	9549-0001-00		Ball bearing	
22	2	2	9699-0100-02		Washer	
23	2	2	1111-2077-01		Hub cap	
24	2	2	1111-1638-01		Washer	
25	2	2	1111-1016-01		Locking handle	
26	2	2	9595-0235-00		Locating pin	
27	2	2	1111-1087-02		Tensioning rod	
28	2	2	9739-0831-22		Nut	
29	4	4	9942-0816-16		Screw	
30	2	2	1111-1078-01		Handle attachment	
31	2	2	1111-1019-01		Adjusting plate	
32	2	2	9997-0816-16		Screw	
33	2	2	9747-0831-02		Lock nut	
34	2	2	1111-0035-01		.Locking knob	
34	1	1	1111-9030-02		Handle bolt kit	
35	2	2	1111-0178-00		.Reinforcement	
36	2	2	9699-0025-02		.Washer	
37	2	2	9899-3551-12		.Screw	
38	5	5	1111-2018-01		Cable holder	
39	5	5	9836-9216-12		Screw	
40	1	1	1111-1076-01		Handle-lower part	
41	1	1	1111-2483-01		Handle-upper part	
42	1	1	1111-3062-01		Eyelink	
48	1	1	1111-2365-02		Gas control	
49	2	2	9948-0645-16		Screw	
50	2	2	9799-0631-02		Nut	
51	1	1	1111-1987-02		Control knob-black	
52	1	1	1111-2473-01		Control handle-R.H.	
53	1	1	1111-2485-01		Engine brake cable	
55	2	2	9595-0160-00		Locating pin	
57	2	2	1111-2295-01		Gear house bracket	
58	2	2	1111-2304-02		Plastic tube	
59	1	1	1111-2299-02		Shaft	
61	1	1	9579-0003-00		Cable holder	
62	1		1111-2430-01		Panel	
62		1	1111-2467-01		Panel	
63		1	9400-0186-00		Starting switch ass	
64		1	1134-2848-01		.Ignition key	
65	2	2	9948-0630-16		Screw	
66	2	2	9747-0631-02		Lock nut	
67		1	1111-2024-01		Wire harness	
68		1	9578-0010-00		Cable clip	
69		1	9947-0512-16		Screw	
72		1	9400-0218-00		Battery	
73		1	9400-0219-00		Charger	
79	1	1	1111-2349-01		Heat guard	