



450S (24-2313-32)

450 (24-2332-22)
450E (24-2336-22)



Section: 450S (Norway) 450 (Denmark) 450E (Denmark)

| Pos. | Quantity | | Spare part No | Description | Kit | Notes | New |
|------|----------|------|---------------|--------------|-----|---------------------|--------------|
| | 2313 | 2332 | 2336 | | | | |
| 1 | | | 1 | 1117-1216-01 | | Deck-yellow | |
| 1 | 1 | 1 | | 1117-1144-01 | | Deck-yellow | |
| 2 | 1 | | | 1117-1160-01 | | Shaft-backside | |
| 2 | | 1 | 1 | 1117-1173-01 | | Shaft-backside | |
| 3 | 2 | 2 | 2 | 9595-0212-00 | | Locating pin | |
| 4 | 2 | 2 | 2 | 1117-1129-01 | | Wheel protection ca | |
| 5 | 2 | 2 | 2 | 1117-1174-01 | | Height adjust lever | |
| 6 | 2 | 2 | 2 | 1111-2665-01 | | Wheel assy | Inkl. pos 74 |
| 7 | 2 | 4 | 4 | 9694-0003-00 | | Washer | |
| 8 | 1 | 1 | 1 | 1117-1146-01 | | Baffle-rear | |
| 9 | 11 | 11 | 11 | 9836-9516-12 | | Screw | |
| 10 | 1 | 1 | 1 | 1117-1156-01 | | Rear flap-yellow | |
| 11 | 1 | 1 | 1 | 1117-1143-01 | | Shaft | |
| 12 | 2 | 2 | 2 | 1117-1126-01 | | Spring-rear flap | |
| 13 | 1 | 1 | 1 | 1117-1155-01 | | Flap holder-yellow | |
| 14 | 1 | 1 | 1 | 1117-1145-01 | | Baffle-front | |
| 15 | 2 | | | 1117-1215-01 | | .Pin | |
| 15 | | 2 | 2 | 9699-0036-02 | | Flat washer | |
| 16 | | 4 | 4 | 1117-1109-01 | | Ball bearing | |
| 16 | 2 | | | 1117-1228-01 | | Adjusting lever | Inkl. pos 15 |
| 17 | | 1 | 1 | 1117-1172-01 | | Shaft-front | |
| 17 | 2 | | | 1117-1194-01 | | Wheel cover | |
| 18 | 2 | | | 1117-1213-01 | | Sector | |
| 18 | | 2 | 2 | 9595-0208-00 | | Locating pin | |
| 19 | 2 | | | 1117-1182-01 | | Shoulder bolt | |
| 19 | | 1 | 1 | 1117-1130-01 | | Connection rod | |
| 20 | | 2 | 2 | 1117-1220-01 | | Wheel | |
| 20 | 2 | | | 1117-1167-01 | | Wheel | |
| 21 | 2 | 2 | 2 | 1111-2804-01 | | Hub cap-yellow | |
| 22 | 2 | 2 | 2 | 1111-2815-01 | | Hub cap-yellow | |
| 23 | 6 | 6 | 6 | 1117-1131-01 | | Nut | |
| 24 | 4 | 4 | 4 | 9699-0028-02 | | Flat washer | |
| 25 | 4 | 4 | 4 | 9997-0820-16 | | Screw | |
| 26 | 2 | 2 | 2 | 9899-3576-12 | | Screw | |
| 27 | 2 | 2 | 2 | 9836-9512-12 | | Screw | |
| 28 | 4 | 4 | 4 | 9699-0025-02 | | Washer | |
| 29 | 1 | 1 | 1 | 9579-0008-00 | | Cable holder | |
| 30 | 2 | 2 | 2 | 1111-3023-01 | | Locking knob | |
| 31 | 4 | 4 | 4 | 9799-0831-02 | | Nut | |
| 32 | 2 | 2 | 2 | 9799-0631-02 | | Nut | |
| 33 | 1 | 1 | 1 | 1117-1149-01 | | Handle-lower part | |
| 34 | 1 | 1 | 1 | 1111-2957-01 | | Handle-upper | |
| 35 | 1 | 1 | 1 | 1111-2953-01 | | Control handle | |
| 36 | 1 | | | 1117-1188-01 | | Throttle control | |
| 36 | | 1 | 1 | 1117-1189-01 | | Throttle control | |
| 37 | 1 | 1 | 1 | 1117-1157-01 | | Grassbag cover-yell | Inkl. pos 68 |
| 38 | 1 | 1 | 1 | 1117-1218-01 | | Lower grass bag | |
| 39 | 1 | 1 | 1 | 9997-0830-16 | | Screw | 30 MM |
| 40 | 2 | | | 9747-0831-02 | | Lock nut | |
| 41 | 6 | 6 | 6 | 9678-0009-02 | | Lock washer | |
| 42 | 1 | 1 | 1 | 9600-0014-00 | | Key | |
| 43 | 1 | 1 | 1 | 1117-1230-01 | | Blade mount | |
| 44 | 1 | 1 | 1 | 1117-1203-01 | | Blade | |
| 45 | 1 | 1 | 1 | 1111-2954-01 | | Control handle | |
| 46 | 1 | 1 | 1 | 1117-1210-01 | | Washer | Inkl. pos 72 |
| 47 | 1 | 1 | 1 | 9987-5251-12 | | Screw | |
| 48 | 2 | 4 | 4 | 9997-0614-16 | | Screw | |
| 49 | | 4 | 4 | 1117-1175-01 | | Washer | |
| 49 | 2 | | | 9699-0085-02 | | Flat washer | |
| 50 | 1 | 1 | 1 | 1117-1120-01 | | Spring | |
| 51 | 2 | 2 | 2 | 9591-0011-00 | | Pin | |
| 52 | 2 | 2 | 2 | 1117-1083-01 | | Safety ring | |
| 53 | 4 | 4 | 4 | 1117-1121-01 | | Bushing | |
| 54 | 2 | 2 | 2 | 1117-1115-01 | | Toothed wheel | |
| 55 | 1 | 1 | 1 | 1117-1200-01 | | Clutch cable | |
| 56 | 2 | 2 | 2 | 9795-3531-02 | | Nut | |

Section: 450S (Norway) 450 (Denmark) 450E (Denmark)

| Pos. | Quantity | | Spare part No | Description | Kit | Notes | New |
|------|----------|------|---------------|--------------|-----|---------------------|------------------|
| | 2313 | 2332 | 2336 | | | | |
| 57 | 1 | 1 | 1 | 1111-2969-01 | | .Cable attachment | |
| 58 | 2 | 2 | 2 | 1111-2955-01 | | Hand holder | |
| 59 | 1 | 1 | 1 | 1117-1113-01 | | V-belt | |
| 60 | 2 | 2 | 2 | 9997-0840-16 | | Screw | 40 MM |
| 61 | 2 | 2 | 2 | 9699-0062-02 | | Flat washer | |
| 62 | 1 | 1 | 1 | 1117-1147-01 | | Transmission cap | |
| 63 | 2 | 2 | 2 | 1111-2575-01 | | Handle holder-inner | |
| 63 | | 2 | 2 | 9865-0816-16 | | Screw | |
| 64 | 2 | 2 | 2 | 1111-2574-01 | | Compr.spring | |
| 64 | | 2 | 2 | 1117-1161-01 | | Wheel protection | |
| 65 | 1 | 1 | 1 | 1111-2927-01 | | Battery holder | |
| 66 | 2 | 2 | 2 | 9549-0043-00 | | Ball bearing | |
| 67 | 2 | 2 | 2 | 1117-1211-01 | | Key | |
| 68 | 1 | 1 | 1 | 1117-1135-01 | | .Cover-yellow | |
| 69 | 1 | 1 | 1 | 1117-1117-01 | | .Pulley | |
| 70 | 1 | 1 | 1 | 1111-2382-01 | | .Pin | |
| 71 | | 1 | 1 | 1117-1118-01 | | Gearbox | Inkl. pos 69, 70 |
| 71 | 1 | | | 1117-1178-01 | | Gear box assy | Inkl. pos 69, 70 |
| 72 | 1 | 1 | 1 | 1134-3203-04 | | .Cable protector | |
| 73 | 1 | | | 1117-1205-01 | | Engine brake cable | Inkl. pos 57 |
| 73 | | 1 | 1 | 1117-1206-01 | | Engine brake cable | Inkl. pos 57 |
| 74 | 2 | 2 | 2 | 1111-9047-01 | | .Ball bearing kit | |
| 75 | 1 | 1 | 1 | 1117-1116-01 | | Rope holder | |
| 76 | 2 | | | 1117-1176-01 | | Wheel bolt | |
| 77 | 4 | | | 1117-1193-01 | | Wheel bushing | |
| 78 | 2 | 2 | 2 | 9948-0640-16 | | Screw | |
| 79 | | | 1 | 9400-0218-00 | | Battery | |
| 80 | | | 1 | 1117-1181-01 | | Harness | |
| 81 | | | 2 | 9836-9540-12 | | Screw | |
| 82 | | | 2 | 9836-9216-12 | | Screw | |
| 83 | | | 1 | 1111-2020-01 | | Housing | |
| 84 | | | 1 | 1111-2021-01 | | Cover | |
| 85 | | | 1 | 9400-0219-00 | | Charger | |
| 86 | | | 1 | 1117-1180-01 | | Cable fixation | |
| 87 | | | 1 | 1117-1204-01 | | Screw | |
| 88 | | | 1 | 1134-2848-01 | | Ignition key | |
| 89 | | | 1 | 9836-9512-12 | | Screw | |
| 90 | | | 1 | 9400-0186-00 | | Starting switch ass | |