



STIGA
400F
SPARE PARTS

Section: RIDER 600-GARDEN CHASSIS STEERING

| Pos. | Quantity | | Spare part No | Description | Kit | Notes | New |
|------|----------|------|---------------|--------------|---------------------|---------------------|-----|
| | 2022 | 2312 | 2333 | | | | |
| 1 | 4 | 4 | 4 | 9997-0890-12 | Screw | | |
| 2 | 17 | 17 | 17 | 9747-0831-02 | Lock nut | | |
| 3 | 2 | 2 | 2 | 1134-3165-01 | Tube plate | | |
| 4 | 2 | 2 | 2 | 1134-3113-01 | Spacer | | |
| 5 | 3 | 3 | 3 | 9997-0830-16 | Screw | | |
| 6 | 4 | 6 | 6 | 9739-0831-22 | Nut | | |
| 7 | 8 | 10 | 10 | 9997-0820-16 | Screw | | |
| 8 | 4 | 4 | 4 | 9699-0090-02 | Flat washer | | |
| 9 | 1 | 1 | 1 | 1134-3192-01 | Steering wheel assy | | |
| 10 | 1 | 1 | 1 | 1134-0341-01 | Washer | 1.5 mm | |
| 10 | 1 | 1 | 1 | 1134-0341-02 | Washer | 0.5 mm | |
| 11 | 2 | 2 | 2 | 9545-0500-00 | Valve | | |
| 12 | 1 | 1 | 1 | 1134-9024-01 | Bearing | Sats 4 st/kit of 4 | |
| 13 | 1 | 1 | 1 | 1134-3190-01 | Steering column | | |
| 14 | 1 | 1 | 1 | 1134-3086-01 | Sprocket | | |
| 15 | 1 | 1 | 1 | 9595-0258-00 | Locating pin | | |
| 16 | 2 | 2 | 2 | 1134-3162-01 | Spacer | | |
| 18 | 1 | 1 | 1 | 1134-3080-02 | Toothed segment | | |
| 19 | 1 | 1 | 1 | 1134-1565-01 | Spacer | | |
| 20 | 4 | 4 | 4 | 9997-0855-12 | Screw | | |
| 21 | 2 | 2 | 2 | 9699-0056-02 | Flat washer | | |
| 22 | 1 | 1 | 1 | 1134-3115-01 | Steering arm | | |
| 23 | 1 | 1 | 1 | 1134-3113-01 | Spacer | | |
| 24 | 1 | 1 | 1 | 1134-2096-02 | Tie rod | | |
| 25 | 2 | 2 | 2 | 9675-0015-02 | Lock washer | | |
| 27 | | 1 | 1 | 1134-1774-01 | Towing eyelet | | |
| 28 | 1 | 1 | 1 | 1134-3140-01 | Bumper | | |
| 29 | 2 | | | 1134-4343-01 | Rim-grey | | |
| 29 | | 2 | 2 | 1134-4343-02 | Rim-yellow | | |
| 30 | 2 | 2 | 2 | 9545-0114-00 | Tyre | 11 x 4.00 - 4 | |
| 30A | | | | 9545-0201-00 | Inner tube | Reservdel/spare par | |
| 31 | 1 | 1 | 1 | 1134-3166-01 | Steering rod sleeve | | |
| 32 | 3 | 3 | 3 | 9599-0080-02 | Cotter pin | | |
| 33 | 1 | 1 | 1 | 1134-4418-01 | Spindle-R.H. | | |
| 34 | 1 | 1 | 1 | 1134-4420-01 | Spindle-L.H. | | |
| 35 | 1 | 1 | 1 | 1134-3107-01 | Front axle bracket | | |
| 36 | 1 | 1 | 1 | 1134-3151-01 | Front axle | | |
| 37 | 1 | 1 | 1 | 1134-3155-01 | Spacer tube | | |
| 38 | 1 | 1 | 1 | 1134-3238-01 | Seat | | |
| 39 | 1 | 1 | 1 | 9988-3919-16 | Screw | | |
| 40 | 1 | | | 1134-3135-03 | Seat bracket-red | | |
| 40 | | 1 | 1 | 1134-3135-01 | Seat bracket-yellow | | |
| 41 | 1 | 1 | 1 | 1134-3138-01 | Seat support | | |
| 42 | 1 | 1 | 1 | 1134-0022-00 | Control rod | | |
| 43 | 2 | 2 | 2 | 9675-0017-02 | Lock washer | | |
| 44 | 2 | 2 | 2 | 1134-3134-01 | Rubber spring | | |
| 45 | | 1 | 1 | 1134-3091-01 | Engine hood-yellow | | |
| 45 | 1 | | | 1134-3091-03 | Engine hood-red | | |
| 46 | | 2 | 2 | 1134-3163-01 | Button | | |
| 47 | | 2 | 2 | 9849-8013-16 | Screw | | |
| 48 | 2 | 2 | 2 | 1134-3139-01 | Tubing | | |
| 49 | 4 | 4 | 4 | 9997-0845-12 | Screw | | |
| 50 | 1 | 1 | 1 | 1134-3247-01 | Tie rod | | |
| 51 | 1 | 1 | 1 | 1134-3167-01 | Locking clip | | |
| 52 | 5 | 5 | 5 | 1134-0341-01 | Washer | | |
| 57 | 1 | 1 | 1 | 1134-3537-02 | Floor mat-L.H. | | |
| 57A | 1 | 1 | 1 | 1134-3149-02 | Floor mat-R.H. | Ej ill/not ill. | |
| 62 | 1 | 1 | 1 | 1134-3281-01 | Strip | | |
| 63 | 1 | 1 | 1 | 1134-9024-01 | Bearing | Sats 4 st/kit of 4 | |
| 64 | 2 | 2 | 2 | 1134-4344-01 | Hub cap | | |
| 65 | 2 | 2 | 2 | 9650-0020-04 | Circlip | | |
| 99 | | 1 | 1 | 1134-3922-01 | Decal kit | | |