



Section: COLLECTOR 48S TRANSMISSION REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	5288					
	-28					
1	1	1111-2808-01	Rear axle			
2	2	1111-2814-01	Bushing			
3	4	9947-0616-16	Screw			
4	5	9838-9522-12	Screw			
5	1	1111-2798-01	Height adj.quadrant			
6	1	1111-2816-01	Height adj.lever			
7	1	1111-2817-01	Lever knob			
8	2	9943-0612-16	Screw			
10	2	1111-2665-01	Wheel assy			
11	1	1111-9047-01	.Ball bearing kit			
12	2	1111-1184-01	..Bearing cone			
15	2	9699-0100-02	Washer			
16	2	9943-0612-16	Screw			
17	2	1111-3085-01	Hub cap-yellow			
20	2	1111-3060-01	Spring			
22	2	1111-2561-01	Cover plate			
23	1	1111-2915-01	Engine belt pulley			
24	1	9910-0612-16	Set screw			
25	1	1111-9061-01	V-belt			
26	1	1111-3046-01	Transmission			
27	1	1111-3047-01	Belt pulley			
28	1	9595-0235-00	Locating pin			
30	1	1111-2822-01	Tension spring			
31	2	1111-2382-01	Pin			
32	2	1111-3256-01	Drive key			
33	2	9404-0083-00	Seal ring			
36	4	9695-0013-00	Washer			
37	2	1111-2829-01	Lock washer			
38	2	1111-3075-01	Pinion plastic whee			
39	2	1111-2830-01	Support washer			
41	2	9652-0010-04	Snap ring			
45	1	1111-3249-01	Clutch cable			
47	1	1117-1374-01	Control handle			
48	1	1111-2969-01	Cable attachment			
49	1	9948-0640-16	Screw			
50	1	9747-0631-02	Lock nut			
53	1	1111-2794-01	Cover-yellow			