



Section: TURBO 55S PRO HERKULES MB 532 TRANSMISSION REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	9204	9604				
	-36	-86				
1	1	1	1111-2808-01		Rear axle	
2	2	2	1111-2814-01		Bushing	
3	4	4	9947-0616-16		Screw	
4	5	5	9838-9522-12		Screw	
5	1	1	1111-2798-01		Height adj.quadrant	
6	1	1	1111-2816-01		Height adj.lever	
7	1	1	1111-2817-01		Lever knob	
8	2	2	9943-0612-16		Screw	
9	2	2	9699-0037-02		Washer	
10	2	2	1111-2345-01		Rear wheel	
11	4	4	9549-0001-00		Ball bearing	
12	2	2	1111-2109-01		Gear ring	
13	8	8	9841-0410-16		Screw	
14	2	2	1111-2423-01		Spacer	
15	2	2	9699-0100-02		Washer	
16	2	2	9943-0620-16		Screw	
17	2	2	1111-2077-01		Hub cap	
18	4	4	9699-0115-02		Washer	
20	2	2	1111-3060-01		Spring	
22	2	2	1111-3229-01		Cover plate	
23	1	1	1111-2915-01		Engine belt pulley	
24	1	1	9910-0612-16		Set screw	
25	1	1	1111-9064-01		V-belt	
26	1	1	1111-3046-01		Transmission	
27	1	1	1111-3047-01		Belt pulley	
28	1	1	9595-0235-00		Locating pin	
30	1	1	1111-2822-01		Tension spring	
31	2	2	1111-2382-01		Pin	
32	2	2	1111-3256-01		Drive key	
33	2	2	9404-0083-00		Seal ring	
36	4	4	9695-0013-00		Washer	
37	2	2	1111-2829-01		Lock washer	
38	2	2	1111-3230-01		Pinion-alum. wheel	
39	2	2	1111-2830-01		Support washer	
41	2	2	9652-0010-04		Snap ring	
45	1	1	1111-2967-01		Clutch cable	
47	1	1	1111-2954-01		Control handle	
48	1	1	1111-2969-01		Cable attachment	
49	1	1	9948-0670-16		Screw	L = 70 mm
50	1	1	9747-0631-02		Lock nut	
53	1	1	1111-3019-01		Cover-yellow	
53		1	1111-3019-04		Cover-red	