



## Section: TURBO 55S-55SE JARDIPRO JP 55 BRICORAMA 53 TA TRANSMISSION

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|-------------|-----|-------|-----|
|------|----------|---------------|-------------|-----|-------|-----|

|      |      |      |   |   |              |                     |
|------|------|------|---|---|--------------|---------------------|
|      |      |      |   |   | 9204         |                     |
|      |      |      |   |   | -16          |                     |
|      | 9289 |      |   |   | 9604         |                     |
| 9288 | 9689 | 9687 |   |   | -16          |                     |
| 1    | 1    | 1    | 1 | 1 | 1111-2808-01 | Rear axle           |
| 2    | 2    | 2    | 2 | 2 | 1111-2814-01 | Bushing             |
| 3    | 4    | 4    | 4 | 4 | 9947-0616-16 | Screw               |
| 4    | 5    | 5    | 5 | 5 | 9838-9522-12 | Screw               |
| 5    | 1    | 1    | 1 | 1 | 1111-2798-01 | Height adj.quadrant |
| 6    | 1    | 1    | 1 | 1 | 1111-2816-01 | Height adj.lever    |
| 7    | 1    | 1    | 1 | 1 | 1111-2817-01 | Lever knob          |
| 8    | 2    | 2    | 2 | 2 | 9943-0612-16 | Screw               |
| 10   | 2    | 2    | 2 | 2 | 1111-3026-01 | Wheel w.ball bearin |
| 11   | 1    | 1    | 1 | 1 | 1111-9047-01 | .Ball bearing kit   |
| 12   | 2    | 2    | 2 | 2 | 1111-1184-01 | ..Bearing cone      |
| 13   | 1    | 1    | 1 | 1 | 9549-0001-00 | .Ball bearing       |
| 15   | 2    | 2    | 2 | 2 | 9699-0100-02 | Washer              |
| 16   | 2    | 2    | 2 | 2 | 9943-0612-16 | Screw               |
| 17   | 2    | 2    | 2 | 2 | 1111-3086-01 | Hub cap-yellow      |
| 17   |      |      | 2 | 2 | 1111-3086-07 | Hub cap-grey        |
| 20   | 2    | 2    | 2 | 2 | 1111-3060-01 | Spring              |
| 22   | 2    | 2    | 2 | 2 | 1111-2561-01 | Cover plate         |
| 23   | 1    | 1    | 1 | 1 | 1111-2915-01 | Engine belt pulley  |
| 24   | 1    | 1    | 1 | 1 | 9910-0612-16 | Set screw           |
| 26   | 1    | 1    | 1 | 1 | 1111-3046-01 | Transmission        |
| 27   | 1    | 1    | 1 | 1 | 1111-3047-01 | Belt pulley         |
| 28   | 1    | 1    | 1 | 1 | 9595-0235-00 | Locating pin        |
| 30   | 1    | 1    | 1 | 1 | 1111-2822-01 | Tension spring      |
| 31   | 2    | 2    | 2 | 2 | 1111-2382-01 | Pin                 |
| 32   | 2    | 2    | 2 | 2 | 1111-3256-01 | Drive key           |
| 33   | 2    | 2    | 2 | 2 | 9404-0083-00 | Seal ring           |
| 36   | 4    | 4    | 4 | 4 | 9695-0013-00 | Washer              |
| 37   | 2    | 2    | 2 | 2 | 1111-2829-01 | Lock washer         |
| 38   | 2    | 2    | 2 | 2 | 1111-3075-01 | Pinion-plastic whee |
| 39   | 2    | 2    | 2 | 2 | 1111-2830-01 | Support washer      |
| 41   | 2    | 2    | 2 | 2 | 9652-0010-04 | Snap ring           |
| 45   | 1    | 1    | 1 | 1 | 1111-2967-01 | Clutch cable        |
| 46   | 1    | 1    | 1 | 1 | 1111-2969-01 | Cable attachment    |
| 47   | 1    | 1    | 1 | 1 | 1111-2954-01 | Control handle      |
| 49   | 1    |      |   |   | 9948-0640-16 | Screw               |
| 49   |      | 1    |   |   | 9948-0660-16 | Screw               |
| 49   |      |      | 1 |   | 9948-0670-16 | Screw               |
| 50   | 1    | 1    | 1 | 1 | 9747-0631-02 | Lock nut            |
| 53   | 1    | 1    |   | 1 | 1111-3019-01 | Cover-yellow        |
| 53   |      |      | 1 | 1 | 1111-3019-06 | Cover-grey          |
| 53   |      | 1    | 1 |   | 1111-3019-08 | Cover-green         |
| 66   | 1    | 1    | 1 | 1 | 1111-9064-01 | V-belt              |

9604-16, 9687-16

L = 40 mm

L = 60 mm

L = 70 mm

9204-16

9604-16, 9687-16

9687-66, 9689