



Section: ESTATE MASTER BODY WORK

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2511					
1	1	1136-0585-01	Cover-front			
2	1	1136-0415-01	Cover-rear			
3	1	1136-0571-01	Footboard cover		Inkl. pos 29, 30	
4	1	1136-0382-01	Grass bag cover-fix			
5	1	1136-0383-01	Grass bag cover-mob			
6	1	1136-0381-01	Engine cover			
7	1	1136-0378-01	Front cover			
8	1	1136-0572-01	Wheel cover			
9	10	9836-9618-12	Screw			
10	8	9836-9635-12	Screw			
11	2	9699-0060-02	Flat washer			
12	2	9941-0512-16	Screw			
13	2	1136-0011-01	Lock plate			
15	2	9997-0616-16	Screw			
16	4	9699-0060-02	Flat washer			
17	2	9747-0631-02	Lock nut			
18	2	1136-0375-01	Bushing			
19	2	1136-0393-01	Spring			
20	2	9997-0845-12	Screw			
21	2	1136-0014-01	Washer			
22	2	9747-0831-02	Lock nut			
23	2	1136-0404-01	Plate			
24	4	9836-9618-12	Screw			
25	2	1136-0405-01	Plate			
26	2	9836-9618-12	Screw			
27	4	9847-8116-16	Screw			
28	4	9699-0035-02	Flat washer			
29	1	1136-0379-01	.Footboard cover-RH			
30	1	1136-0380-01	.Footboard cover-LH			
41	1	1136-0556-01	Throttle control			
42	2	9997-0412-16	Screw			
43	2	9683-0010-02	Washer			
44	1	1136-0192-01	Handle			
45	1	9865-0412-16	Screw			
46	1	9799-0431-02	Nut			
51	1	1136-0315-01	Nut			
52	1	1136-0336-01	Support			
53	1	1136-0252-01	Seat plate			
54	4	9997-0820-16	Screw			
55	4	9683-0030-02	Lock washer			
56	4	9699-0056-02	Flat washer			
61	1	1136-0360-01	Steering wheel			
62	1	9595-0272-00	Pin			
71	1	1136-0275-01	Guard-upper			
72	1	1136-0276-01	Guard-lower			
73	2	9847-8038-16	Screw			
74	2	9699-0024-02	Flat washer			
75	2	1136-0010-01	Lock plate			
81	1	1136-0419-01	Fuel tank			
82	1	1136-0344-01	Tank cap			
83	1	1136-0591-01	Tank support			
84	6	9739-0831-22	Nut			
85	1	1136-0368-01	Tank clamp			
86	2	9747-0631-02	Lock nut			