



## Section: PARK PRO 16-PRO 20-DIESEL TRANSMISSION

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	6216	6221	6231				
1	1	1	1	1134-4000-01		Tension arm	
2	1	1	1	1134-3459-01		Tension roller	
3	1	1	1	9924-1035-16		Screw	
4	1	1	1	9799-1031-02		Nut	
5	1	1	1	1134-9029-01		V-belt	= 9585-0055-00
6	1	1	1	1134-3377-03		Control rod	
7	1	1	1	9675-0008-02		Locking washer	
8	1	1	1	1134-4171-01		Pivot pin	
9	1	1	1	1134-4183-01		Compression spring	
10	2	2	2	1134-3456-01		Bushing	
11	1	1	1	9747-0631-02		Lock nut	
12	1	1	1	1134-1565-08		Spacer	
13	1	1	1	9997-0875-12		Screw	
14	1	1	1	9699-0056-02		Flat washer	
15	1	1	1	9747-0831-02		Lock nut	
16	1	1	1	1134-3211-02		Spring	
17	1			1134-4849-01		Transaxle	Kanzaki K62E
17		1	1	1134-4850-01		Transaxle	Kanzaki K66B
18	2	2	2	1134-3376-01		Spacer plate	
19	4	4	4	9997-0875-12		Screw	L = 75 mm
20	4	4	4	9747-0831-02		Lock nut	
21		2	2	1134-4282-01		Hydraulic nipple	
21A		1	1	9404-0028-01		.O-ring	
22	1	1	1	1134-3913-01		Strut	
23	1	1	1	9959-0820-16		Screw	L = 20 mm
23	1	1	1	9959-0825-16		Screw	L = 25 mm
24	2	2	2	9747-0831-02		Lock nut	
25	1	1	1	1134-4191-01		Belt pulley	
26	1	1	1	1134-4190-01		Fan	
27	1	1	1	9699-0030-02		Flat washer	
28	1	1	1	9747-1031-02		Lock nut	
29	1	1	1	1134-3914-01		Cable holder	
30	1	1	1	9959-0820-16		Screw	
31	1	1	1	9739-0831-22		Nut	
32	1	1	1	1134-4049-01		Strut	
33	1	1	1	1134-4232-01		Spring	
34B	1	1	1	1134-4758-01		Oil tank	
35	1	1	1	1134-2777-02		Filler cap	
36	1	1	1	1134-3734-01		Vent plug	
37	2	2	2	9945-0816-16		Screw	
38B	1	1	1	1134-4011-02		Oil hose	L = 380 mm
39	2	2	2	9578-0025-01		Hose clamp	
40	1	1	1	9579-0003-00		Cable holder	
50	1	1	1	1134-4015-01		Pull rod	
51	1	1	1	1134-4014-01		Plastic button	
52	1	1	1	1134-4713-01		Bracket	
53	1	1	1	1134-2790-01		Rubber grommet	
54	1	1	1	9959-0816-16		Screw	
55	1	1	1	9739-0831-22		Nut	
56	1	1	1	9675-0009-02		Starlock	