



## Section: SB 40-SB 44-SB 52 BRUSH CUTTER GEAR CASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		6115				
	4629	4630				
1	1	1911-3138-01	Gear case assy		Inkl. pos 2 - 21	
1	1	1911-3137-01	Gear case assy		Inkl. pos 2 - 21	
1A	1	1911-3161-01	Gear case			
1A	1	1911-3162-01	Gear case			
2	1	1911-3067-01	.Lock ring			
3	1	1911-3065-01	.Lock ring			
4	1	1911-3037-01	.Ball bearing			
5	1	1911-3036-01	.Ball bearing			
6	1	1911-3182-01	.Worm gear			
6	1	1911-3183-01	.Worm gear			
7	2	1911-3008-01	.Screw			
8	1	1911-3025-01	.Screw			
9	1	1911-3029-01	.Screw			
10	1	1911-3038-01	.Ball bearing			
11	1	1911-3015-01	.Washer			
12	1	1911-3049-01	.Key			
13	1	1911-3034-01	.Ball bearing			
14	1	1911-3066-01	.Lock ring			
15	1	1911-3045-01	.Oil seal			
16	1	1911-3082-01	.Collar			
17	1	1911-3081-01	.Ring nut-upper			
18	1	1911-3070-01	.Ring nut-lower			
19	1	1911-3163-01	.Bowl assy (fixed)		Inkl. pos 20 - 21	
20	1	1911-3018-01	..Washer			
21	1	1911-3026-01	..Screw (LH-thread)			
22	1	1911-3076-01	Cup			
23	1	1911-3154-01	Nylon head (Profi)		Inkl. pos 25 - 28	
23A	1	1911-9008-08	Cutting line (2.4 m)		15 m	
23A	1	1911-9008-04	Cutting line (2.4 m)		0.45 kg (90 m)	
24	1	1911-3181-01	Saw blade		24T - Ø 225 mm	
25	2	1911-3085-01	.Bushing			
26	1	1911-3213-01	.Spring			
27	1	1911-3214-01	.Coil			
28	1	1911-3215-01	.Cover			
29	1	1911-3179-01	Clearing blade		4T - Ø 255 mm	