



STIGA
1468
SPARE PARTS

Section: HERKULES MB532 HANDLE TRANSMISSION 4-SPEED

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	9604					
	-87					
1	1	1111-2957-01	Handle-upper			
2	1	1111-3022-01	Handle-lower			
3	2	1111-3021-01	Handlebar attachmen			
4	2	1111-3024-01	Attachment plate			
5	4	1111-3023-01	Locking knob			
6	4	9795-3531-02	Nut			
7	6	9699-0028-02	Flat washer			
8	2	1111-0178-00	Reinforcement			
9	2	9899-3545-12	Screw		L = 45 mm	
10	2	9899-3557-12	Screw		L = 57 mm	
11	2	9939-0820-16	Screw			
12	1	1111-3062-01	Eyelink			
13	1	9900-0060-00	Allen wrench			
20	1	9948-0670-16	Screw		L = 70 mm	
21	1	9747-0631-02	Lock nut			
22	1	1111-2953-01	Control handle			
23	1	1111-2968-07	Engine brake cable			
24	3	1111-2018-01	Cable holder			
25	3	9836-9216-12	Screw			
26	1	1111-3301-03	Throttle control			
28	1	1111-2954-01	Control handle			
29	1	1111-3388-01	Clutch cable			
30	1	1111-2969-01	Cable attachment			
31	1	1111-2971-03	Variator control			
31A	1	1111-2941-01	.Knob			
31B	2	9838-9522-12	.Screw			
32	2	9838-9540-12	Screw			
40	1	1111-2433-01	Engine belt pulley			
41	1	9910-0612-16	Set screw			
42	1	9585-0137-01	Drive belt			
44	1	1111-3393-01	Transmission			
44A	1	1111-3446-01	.Spring		Ej ill/not ill.	
45	1	1111-3001-01	Variator assy			
46	1	9594-0026-00	Locating pin			
47	2	9404-0083-00	Seal ring			
48	2	1111-2382-01	Pin			
49	2	9695-0013-00	Washer			
50	2	1111-2829-01	Lock washer			
51	2	1111-3256-01	Drive key			
52	2	1111-3230-01	Pinion-alum. wheel			
53	2	1111-2830-01	Support washer			
54	2	9695-0013-00	Washer			
55	2	9652-0010-04	Snap ring			
60	1	9943-0650-16	Screw			
61	1	1111-3051-01	Tension arm			
62	1	1111-2746-01	Belt pulley			
63	1	1111-2747-01	Tension roller			
64	1	1111-3050-01	Bracket			
65	1	1111-2423-01	Spacer			
66	1	9838-9522-12	Screw			
67	2	9947-0616-16	Screw			
68	1	1111-2469-01	Attachment			
69	2	9699-0060-02	Flat washer			
70	1	9997-0630-12	Screw			
71	1	9747-0631-02	Lock nut			