



Section: 1384 HANDLE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2862					
720	1	1812-1812-01	Handle-upper			
724	4	9988-3764-12	Screw			
725	6	9699-0035-02	Flat washer			
726	4	9683-0035-02	Lock washer			
727	4	9795-3731-02	Nut			
728	2	1812-0830-01	Plastic stop			
739	2	1812-0520-01	Protection			
740	1	1812-1729-01	Clutch cable			
741	1	1812-1519-01	Control wire			
743	1	1133-0977-01	Cable adjust bracke			
744	1	1812-0254-01	Spring			
745	2	1812-1760-01	Nut			
750	1	1812-0553-01	Handle-lower			
751	4	1133-0057-01	Screw			
752	4	9683-0030-02	Lock washer			
756	2	1133-0968-01	Clutch spring boot			
758	1	1812-1772-01	Screw			
759	1	1812-1205-01	Spool			
760	1	1812-1702-01	Bracket			
762	1	1812-1727-01	Drive cable-lower			
770	1	1812-1811-01	Shift bracket			
771	1	9988-3751-12	Screw			
772	1	1812-0304-01	Spring			
773	1	9699-0035-02	Flat washer			
774	1	9743-3721-32	Nut			
785	1	9743-3721-32	Nut			
787	1	1133-0650-01	Handle			
790	1	1812-1414-01	Bail rod-LH			
791	1	1812-1188-01	Bail rod-R.H.			
795	1	1812-1593-01	Cam retainer bracke			
796	1	1812-1765-01	Screw			
798	1	9743-3621-32	Nut			
799	1	1812-0834-01	Cam lock spring			
800	1	1812-1280-01	Pin latch			
801	2	1812-1483-01	Retainer			
802	1	9599-0036-02	Split pin			
803	1	9699-0029-02	Flat washer			
804	1	1812-1773-01	Speed control rod			
808	1	1812-1776-01	Trunion nut			
809	1	9699-0029-02	Flat washer			
810	1	9599-0036-02	Split pin			
811	1	1812-1219-01	Plastic bushing			
812	1	1812-1720-01	Yoke rod			
813	1	1812-1672-01	Retainer ring			