



Section: 2500-3000-2500M EL.TRIMMER

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		1133	1134	1132			
1	1	1	1	1911-0704-02		Connection cable	
2	1	1	1	1911-0702-01		Switch	
3	1	1	1	1911-0817-01		Handle L+R	
5	1		1	1911-0710-02		Tube	
5		1		1911-0729-01		Tube	
6	1	1	1	1911-0818-01		Motorhousing L+R	
7	1	1	1	1911-0718-01		.Blade	
11	13	13	13	1911-0820-01		Screw	
13	1	1	1	1911-0697-01		Cable holder	
14	1	1	1	1911-0732-01		Engine plate	
15	1	1	1	1911-0825-01		Condensor	
16	1	1		1911-0850-01		Cutting head assy	
17	1	1		1911-0851-02		.Drive plate	
18	1	1		1911-0852-01		.Spring	
19	1	1		1911-9004-01		.Spool w.line	
20	1	1		1911-9005-07		..Cutting line (1.2	
22	1	1		1911-0725-02		.Head cap	
23	1	1	1	1911-0738-01		Clamp	
24	3	3	3	1911-0824-01		Screw	
26	1	1	1	1911-0727-01		Engine cover	
28		1		1911-0728-02		Helpers handle	
29	4	4	4	1911-0822-01		Screw	
30	1	1	1	1911-0764-01		Gasket	
31	1	1	1	1911-0763-01		Gasket	
32			1	1911-0819-01		Cutting head assy	
33			1	1911-9003-01		.Spool w.line	
34			1	1911-9005-07		..Cutting line (1.2	
35	1	1	1	1911-0821-01		Screw	
36	1	1	1	1911-0823-01		Screw	

TEST