



Section: GR 22 PETROL TRIMMER CARBURETTOR

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------------|-----|-------|-----|
| | 1129 | | | | | |
| 0 | 1 | 1911-0870-01 | Carburettor assy | | | |
| 1 | 2 | 1911-0894-01 | .Screw | | | |
| 2 | 1 | 1911-0893-01 | .Cover | | | |
| 3 | 1 | 1911-0892-01 | .Diaphragm | | | |
| 4 | 1 | 1911-0891-01 | .Gasket | | | |
| 5 | 1 | 1911-0890-01 | .Screw | | | |
| 6 | 1 | 1911-0889-01 | .Pin | | | |
| 7 | 1 | 1911-0881-01 | .Lever | | | |
| 8 | 1 | 1911-0880-01 | .Spring | | | |
| 9 | 1 | 1911-0888-01 | .Needle valve | | | |
| 10 | 1 | 1911-0886-01 | .Clip | | | |
| 11 | 1 | 1911-0895-01 | .Welch plug | | | |
| 12 | 1 | 1911-0875-01 | .Throttle valve | | | |
| 13 | 1 | 1911-0874-01 | .Screw | | | |
| 14 | 2 | 1911-0878-01 | .Spring | | | |
| 15 | 1 | 1911-0879-01 | .High speed needle | | | |
| 17 | 1 | 1911-0877-01 | .Idle needle | | | |
| 18 | 1 | 1911-0873-01 | .Spring | | | |
| 19 | 1 | 1911-0876-01 | .Throttle shaft | | | |
| 20 | 1 | 1911-0885-01 | .Clip | | | |
| 21 | 1 | 1911-0896-01 | .Swivel | | | |
| 24 | 1 | 1911-0884-01 | .Strainer | | | |
| 25 | 1 | 1911-0872-01 | .Diaphragm | | | |
| 26 | 1 | 1911-0883-01 | .Gasket | | | |
| 27 | 1 | 1911-0882-01 | .Cover | | | |
| 28 | 2 | 1911-0871-01 | .Screw | | | |
| 29 | 1 | 1911-0887-01 | .Idle adjust screw | | | |
| 30 | 1 | 1911-0897-01 | .Friction piece | | | |

TEST