



test

Section: GR 22 PETROL TRIMMER IGNITION SYSTEM STARTER

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

1129

5	1	1911-0564-01	Stopper			
6	1	1911-0640-01	Circlip			
7	1	9549-0001-00	Ball bearing			
8	1	1911-0642-01	Circlip			
9	1	1911-0926-01	Clutch drum			
10	1	1911-0925-01	Clutch			
16	1	1911-0921-01	Ground lead			
17	1	1911-0968-01	Screw			
18	1	1911-0861-01	Washer			
19	1	1911-0922-01	Flywheel			
20	1	1911-0920-01	Ignition module			
21	2	1911-0967-01	Screw			
22	2	1911-0919-01	Spacer			
23	1	1911-0918-01	Bushing			
24	1	1911-0556-02	Spark plug cap			
25	1	1911-0555-02	Cap coil			
26	1	1911-0923-01	Spark plug		NGK BPM-7A	
32	1	1911-0928-01	Pawl catcher assy			
33	1	1911-0974-01	.E-ring			
34	1	1911-0929-01	.Pawl catcher			
35	1	1911-0937-01	.Spring			
36	1	1911-0932-01	.Srarter pawl			
38	1	1911-0634-01	Nut			
40	1	1911-0927-01	Starter assy			
41	1	1911-0938-01	.Screw			
42	1	1911-0930-01	.Washer			
43	1	1911-0931-01	.Starter drum			
44	1	1911-0934-01	.Starter rope			
45	1	1911-0935-01	.Rope guide			
46	1	1911-0574-01	.Starter grip			
47	1	1911-0933-01	.Rewind spring			
48	1	1911-0936-01	.Starter case			
51	2	1911-0966-01	Screw			