



Section: 465 VARIOSPEED

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	9122					
1	1	1117-0121-01	Chassie			
2	1	1117-0163-01	Flap attachment-L.H			
3	1	1117-0162-01	Flap attachment-R.H			
4	1	1117-0158-01	Front sign			
5	2	9675-0012-02	Locking washer			
6	1	1117-0133-01	Front wheel axle			
7	2	1117-0154-01	Bushing			
8	2	1117-0182-01	Clamp-front			
9	7	9942-0616-16	Screw			
10	2	1117-0138-01	Front wheel			
11	4	1117-0193-01	Washer			
12	4	1117-0192-01	Hub cap			
13	5	9997-0616-16	Screw			
14	1	1117-0145-01	Rear wheel axle			
15	1	1117-0147-01	Drive shaft			
16	2	1117-0183-01	Pin			
17	2	1117-0123-01	Pawl holder			
18	4	1117-0122-01	Pawl			
19	2	1117-0124-01	Spring			
20	2	1117-0125-01	Pinion			
21	2	9650-0014-04	Lock ring			
22	2	1117-0130-01	Washer			
23	2	1117-0139-01	Rear wheel			
24	1	1117-0110-01	Locating pin			
25	1	1117-0191-01	Variator assy.			
26	1	1117-0119-01	V-belt			
27	1	9650-0018-04	Circlip			
28	1	1117-0112-01	Bearing			
29	1	1117-0188-01	Worm			
30	1	1117-0111-01	Ball bearing			
31	1	1117-0141-01	Worm gear housing			
32	2	1117-0115-01	Seal			
33	2	1117-0148-01	Bushing			
34	1	1117-0170-01	Spring			
35	2	1117-0169-01	Washer			
36	1	1117-0201-01	Worm gear			
37	1	1117-0201-01	Worm gear			
38	1	1117-0149-01	Clutch sleeve			
39	1	1117-0168-01	Clutch fork			
40	1	1117-0114-01	Seal			
41	1	1117-0116-01	Seal			
42	1	1117-0142-01	Cover			
43	5	1117-0117-01	Screw			
44	1	1117-0146-01	Worm gear assy.			
45	1	1117-0198-01	Tensioning arm assy			
46	1	9699-0028-02	Flat washer			
47	1	1117-0197-01	Bushing			
48	1	9997-0830-16	Screw			
53	1	9799-1031-02	Nut			
54	1	9997-1050-16	Screw			
55	1	1117-0137-01	Button			
56	1	1117-0136-01	Handle			
57	1	1117-0127-01	Lever			
58	2	9948-0616-16	Screw			
59	13	9847-7922-16	Screw			
60	1	1117-0135-01	Cover			
61	1	1117-0180-01	Spring			
62	1	1117-0129-01	Spacer			
63	1	1117-0153-01	Catch			
64	1	1117-0179-01	Spring			
65	1	1117-0129-01	Spacer			
66	2	9699-0035-02	Flat washer			
67	1	1117-0134-01	Tie rod			
68	2	9843-8022-16	Screw			
69	2	1117-0155-01	Bushing			
70	2	1117-0156-01	Clamp-rear			

Section: 465 VARIOSPEED

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	9122					
71	4	9836-9520-12	Screw			
72	1	1117-0181-01	Protection plate			
73	1	1117-0126-01	Guide plate			
74	2	9699-0057-02	Flat washer			
75	1	9799-0631-02	Nut			
76	1	1117-0118-01	Blade bolt			
77	1	1117-0058-02	Blade washer			
78	1	1117-0107-01	Blade			
79	1	1117-0113-01	Washer			
80	1	1117-0157-01	Blade holder			
81	4	9799-0831-02	Nut			
82	3	9997-0835-12	Screw			
84	1	1117-0151-01	Spring-R.H.			
85	1	1117-0144-01	Flap			
86	1	1117-0152-01	Spring-L.H.			
87	2	1117-0150-01	Pivot pin			
88	2	1117-0172-01	Handle tube-lower			
89	4	9997-0845-12	Screw			
90	2	9898-0855-12	Screw			
91	2	1117-0001-01	Locking knob			
92	1	1117-0171-01	Handle-upper part			
93	1	1117-0160-01	Panel-upper part			
94	1	1117-0159-01	Panel-lower part			
95	1	1117-0173-01	Clutch handle			
96	1	1117-0184-01	Spring			
97	1	1117-0174-01	Clutch lever			
98	1	1117-0175-01	Clutch cable assy.			
99	1	1117-0199-01	Variator cable			
100	1	1117-0176-01	Gas cable		Briggs & Stratton	
100	1	1117-0176-02	Gas cable		Tecumseh	
101	2	1117-0161-01	Control tube			
102	1	1117-0164-01	Gas control			
103	2	1117-0167-01	Control knob			
104	1	1117-0166-01	Control guide			
105	1	1117-0165-01	Variator control			
106	1	1117-0177-01	Tube			
107	1	1117-0178-01	Spring			
108	1	1117-0074-01	Cable holder			