


test



## Section: TURBO 420 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2212					
	2512					
	2537					
0	1	1111-2387-01	Right angle drive			
1	1	1111-2295-01	.Gear house bracket			
2	1	1111-2226-01	.Gear housing assy.			
3	1	1111-1852-01	.Cover			
4	8	9943-0512-16	.Screw			
5	1	1111-2067-01	.Cable bracket			
8	1	9747-0531-02	.Nut			
9	1	9699-0024-02	.Flat washer			
10	1	1111-2066-01	.Clutch lever			
11	1	9404-0021-00	.O-ring			
12	1	1111-2048-01	.Engagement lever			
15	1	9997-0612-16	.Screw			
16	1	9699-0060-02	.Flat washer			
17	1	1111-1850-01	.Belt pulley			
18	1	9600-0117-00	.Key			
19	1	9549-0004-00	.Ball bearing			
20	1	1111-1847-01	.Shaft & gear, inpu			
23	2	9548-0003-00	.Flange bearing			
24	2	1111-2249-01	.Washer			
26	1	1111-2166-02	Clutch half, input			
27	1	1111-2390-01	.Clutch spring			
28	1	1111-2184-01	.Clutch sleeve w.sp			
29	1	1111-2218-01	.Clutch half, outpu			
30	1	9594-0045-00	.Locating pin			
31	ERF	9695-0010-00	Washer		Shims 0.5 mm	
31	ERF	9695-0008-00	Washer		Shims 0.2 mm	
31	ERF	9695-0009-00	Washer		Shims 0.3 mm	
33	1	9404-0081-00	.Seal ring			
34	1	1111-2217-01	.Shaft			
35	1	9589-0003-04	Chain			
37	1	1111-1992-01	Chain guard			
38	1	9943-0510-16	Screw			
39	1	1111-2229-01	Chain tensioner			
40	3	9836-9516-12	Screw			
42	1	1111-9056-01	V-belt			
43	1	1111-1993-01	Clutch cable			
44	1	1111-2034-01	Spring			
45	1	1111-2224-01	Rear axle			
46	1	1111-1759-01	Cover plate			
47	1	1111-1966-01	Cover plate			
48	4	9943-0510-16	Screw			
49	4	9799-0531-02	Nut			
50	1	9695-0004-00	Washer			
52	4	9652-0010-04	Snap ring			
53	1	1111-1755-01	Gear wheel			
54	2	1111-1864-01	Key			
55	2	1111-2068-01	Spring			
56	1	1111-1863-01	Drive shaft			
57	2	1111-1756-01	Bushing			
58	1	9699-0069-02	Flat washer			
59	1	1111-1963-01	Sprocket			
60	1	9594-0047-00	Locating pin			
62	1	1111-1755-02	Gear wheel			