



Section: SWEEPER ART.NO 14-1934-11

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		1934				
		9585-0065-00	V-belt			
0		..14-1934-11	Sweeper assy			
1	3	9907-0508-16	Set screw			
2	3	1489-0192-01	Flange bearing			
3	3	1489-0180-01	Screw			
4	1	1489-0179-01	Flange			
5	1	1489-0346-01	Brush shaft			
6	15	1489-0178-01	Spacer			
7	16	1489-0327-01	Brush			
8	6	9997-1025-16	Screw			
9	8	9699-0035-02	Flat washer			
10	5	1489-0182-01	Key			
13	12	9678-0011-02	Lock washer			
14	11	9799-1031-02	Nut			
15	1	1489-0187-01	Sprocket			
16	4	9915-0808-15	Set screw			
17	1	1489-0347-01	Chain			
18	3	1489-0191-01	Chain lock			
19	1	1489-0348-01	Chain guard			
20	12	9678-0009-02	Lock washer			
21	2	9997-0865-12	Screw			
22	2	9997-1040-12	Screw			
23	3	1489-0360-01	Spacer			
24	2	1489-0358-01	Sprocket			
25	6	9549-0004-00	Ball bearing			
26	3	1489-0185-01	Spacer			
29	3	1489-0184-01	Lockring			
30	2	9915-0606-15	Set screw			
31	1	1489-0190-01	Tappet			
32	1	9678-0014-02	Lock washer			
33	1	9799-1631-02	Nut			
34	1	1489-0329-01	Chain			
37	1	1489-0349-01	Sprocket			
41	1	1489-0350-01	Flangebushing			
43	1	9997-1065-12	Screw			
50	1	1489-0351-01	Spacer			
55	1	1489-0352-01	Shaft			
57	1	1489-0353-01	Chain			
58	1	1489-0188-01	Sprocket			
64	1	1489-0211-01	Tube			
66	1	1489-0209-01	Universal joint			
67	1	1489-0330-01	Clutch plate			
68	1	1489-0331-01	Console			
69	2	1489-0344-01	Bracket			
71	8	9699-0028-02	Flat washer			
72	4	9997-0830-16	Screw			
73	1	1489-0393-01	Spring			
74	1	1489-0204-01	Clamp			
75	2	9699-0037-02	Washer			
76	1	9997-1270-12	Screw			
77	2	9847-8013-16	Screw			
78	2	9699-0024-02	Flat washer			
79	2	1489-0414-01	Clip			
80	1	1489-0334-01	Belt guard			
81	1	1489-0333-01	Belt guard			
85	1	1489-0335-01	Belt guard			
86	1	9997-0812-16	Screw			
90	1	1482-0170-01	Grip			
91	2	9751-0821-02	Wing nut			
93	1	1489-0336-01	Cover			
96	5	9799-0831-02	Nut			
97	1	9997-0825-16	Screw			
98	1	1489-0422-01	Knob			
99	1	1489-0337-01	Belt guide			
100	1	1489-0338-01	Clutch shaft			

Section: SWEEPER ART.NO 14-1934-11

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
1934						
101	1	1489-0400-01	Tension roller			
102	1	1489-0399-01	Bushing			
103	1	1489-0405-01	Screw			
105	1	1489-0337-01	Belt guide			
106	1	1489-0332-01	Clutch arm			
107	1	9997-1225-16	Screw			
108	1	9678-0012-02	Lock washer			
110	3	1489-0320-01	Flangebushing			
112	1	1489-0340-01	Nut			
114	1	1489-0359-01	Belt pulley			
115	2	1489-0411-01	Lock ring			
116	2	9549-0027-00	Ball bearing			
117	1	9599-0067-02	Cotter pin			
118	1	1489-0202-01	Shaft			
121	1	1489-0341-01	Housing			
122	1	1489-0328-01	Adjusting lever			
124	1	1489-0342-01	Pivot pin			
125	1	1482-0250-01	Spring			
126	1	1489-0343-01	Pawl			
129	1	1489-0354-01	Frame			
130	2	9650-0015-04	Lock ring			
131	2	1489-0355-01	Spindle			
132	1	9997-1030-16	Screw			
135	2	9699-0102-01	Flat washer			
137	2	9747-0831-02	Lock nut			
138	2	9997-0845-12	Screw			
139	2	1489-0356-01	Tube			
141	2	1489-0412-01	Pin			
142	2	1489-0194-01	Wheel holder			
143	2	1489-0196-01	Screw			
146	2	1489-0321-01	Wheel bushing			
147	2	1489-0195-01	Supporting wheel			
148	1	9997-1020-16	Screw			
152	1	1489-0345-01	Handle bar			
153	3	9898-0820-16	Screw			
157	1	1489-0357-01	Mud guard			
158	3	9751-0631-02	Wing nut			
159	3	9678-0008-02	Lock washer			
160	3	9997-0612-16	Screw			
163	1	1489-0361-01	Guard extension			
175	1	9585-0064-00	V-belt		För hjul 10"	
175	1	9585-0065-00	V-belt		För hjul 15"	