



Section: 1236G-1642H-TRM107 STEERING LIFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	8111					
	8119	8131				
1	4	4	1811-0754-01		Screw	
2	1	1	1132-0337-01		Steering wheel	
3	1	1	1132-0018-01		Roll pin	
4	1	1	1132-0027-01		Flange bearing	
5	1	1	1132-0537-01		Shaft support	
6	13	13	9727-3541-22		Nut	
7	17	17	1132-0690-01		Screw	
8	1		1132-0548-01		Instr. panel suppor	
8		1	1132-0896-01		Instr.panel support	
9	4	4	1132-0023-01		Speed nut	
10	1	1	1132-0828-01		Battery support	
11	2	2	1132-0883-01		Belt guide	
12	1	1	1132-0145-01		Handle grip	
13	4	4	1811-0182-01		Washer	
14	33	38	1132-0691-01		Screw	
15	2	2	1132-0487-01		Lock nut	
16	1	1	1132-0466-01		Steering arm	
17	1	1	1132-0617-01		Washer	
18	2	2	1132-0022-01		Retaining ring	
19	1	1	1132-0300-01		Pin	
20	1	1	1132-0886-01		Lift guide kit	
22	2	2	9699-0038-02		Flat washer	
23	42	42	9727-3641-22		Nut	
24	2	2	1811-0122-01		Cotter pin	
25	1	1	1132-0494-01		Lift rod	
26	1	1	1811-0176-01		Grease fitting	
27	1	1	1132-0761-01		Lift shaft	
28	1	1	1132-0757-01		Fender support	
29	1	1	1132-0447-01		Rear panel	
30	2	2	1132-0158-01		Axle support	
31	1	1	1132-0898-01		Lift lever	
32	2	2	1132-0021-01		Retaining ring	
33	1	1	9652-0015-04		Retaining ring	
34	1	1	1132-0804-01		Rear frame	
35	4	4	1132-0199-01		Angle bracket	
36	1	1	1132-0498-01		Steering shaft	
37	ERF	ERF	1132-0125-01		Shim washer	
38	1	1	1132-0302-01		Flange bearing	
39	1	1	1132-0471-01		Steering support	
40	1	1	1132-0058-01		Thrust washer	
41	1	1	1132-0468-01		Sector gear	
42	2	2	1132-0020-01		Flange bearing	
43	1	1	9650-0019-04		Retainer ring	
44	1	1	1132-0303-01		Bracket	
45	1	1	1132-0470-01		Steering arm	
46	2	2	9988-3757-12		Screw	
47	4	4	9743-3721-32		Nut	
48	4	4	1811-0204-01		Flat washer	
49	2	2	9743-5221-32		Nut	
50	2	2	1132-0063-01		Ball joint	
51	2	2	9743-5421-32		Nut	
52	1	1	1132-0467-01		Steering rod	
53	1	1	1132-0304-01		Bracket	
54	1	1	1132-0481-01		Attachment bracket	
55	4	4	9954-3719-16		Screw	
56	4	4	1132-0695-01		Nut	
57	1	1	1132-0893-01		Lock hex nut	
58	1	1	1132-0894-01		Screw	
59	1	1	1132-0463-01		Spindle-L.H.	
60	1	1	1132-0464-01		Spindle-R.H.	
61	4	4	1132-0453-01		Bushing	
62	2	2	9545-0500-00		Valve	
63	4	4	1811-0190-01		Grease nipple	
64	2	2	1132-0573-01		Wheel	
65	2	2	1132-0454-01		Tire	15 x 6.00-6
66	4	4	1132-0181-01		Flange bearing	

Section: 1236G-1642H-TRM107 STEERING LIFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	8111					
	8119	8131				
67	4	4	1132-0021-01		Retaining ring	
68	ERF	ERF	1811-0200-01		Washer	
69	1	1	1132-0465-01		Front axle	
70	1	1	1132-0483-01		Tire rod	
71	1	1	1132-0185-01		Front frame	
72	1	1	1132-0259-01		Belt guide	
73	2	2	1132-0264-01		Hub cap	
74	ERF	ERF	1811-0182-01		Washer	
75	2	2	1132-0305-01		Cable guide	
76	2	2	9988-3732-12		Screw	
77	2	2	1132-0837-01		Pulley	
78	2	2	1132-0307-01		Spacer	
79	2	2	1132-0510-01		Bracket	
80	1	1	1132-0538-01		Push link	

test