



Section: PARK 12 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1218					
	1258					
	1638					
	5219					
1	1	9997-0835-12	Screw			
1	2	9997-0850-16	Screw			
3	11	9739-0831-22	Nut			
4	1	9942-0825-16	Screw			
5	1	1134-2085-01	Belt guide			
6	1	9650-0016-04	Lock ring			
7	1	1134-1849-01	Belt pulley			
8	2	9959-0816-16	Screw			
9	1	9799-1031-02	Nut			
10	1	1134-9027-01	Tension roller			
11	1	1134-0054-01	Spacer			
13	1	1134-9013-01	V-belt		= 9585-0057-00	
14	1	1134-2020-01	Engine pulley			
15	1	1134-2015-03	Tension arm			
16	1	1134-0645-00	Spring			
17	1	9997-1030-16	Screw			
18	1	1134-2086-01	Belt stirrup			
19	1	9987-5332-16	Screw			
20	1	9987-5016-16	Screw			
22	1	9699-0060-02	Flat washer			
23	6	9739-0531-22	Nut			
24	1	1134-2129-01	Gear shifter arm			
25	2	9570-0001-00	Elbow link			
26	1	1134-2381-01	Belt guide			
27	2	9942-0816-16	Screw			
28	1	1134-2030-04	Clutch cable			
29	1	1134-2031-02	Gear shifter cable			
32	5	9997-0865-12	Screw			
33	1	1134-2469-01	Transaxle assy			
34	2	9545-0116-00	Tyre			
34	2	9545-0103-00	Tyre-tubeless			
34A		9545-0203-00	Inner tube			
36	2	9545-0500-00	Valve			
39	2	1134-2471-01	Key			
40	2	1134-3175-01	Rim-rear			
41	2	9988-3645-16	Screw			
42	2	9743-3621-32	Nut			
43	1	9579-0003-00	Cable holder			
45	1	1134-2551-01	Knob			
46	1	1134-3450-01	Brake pedal (L. H.)			
47	2	1134-9024-01	.Bearing			
48	1	9696-0013-01	Bowed washer			
49	1	1134-2328-01	Gear lever			
51	1	1134-0220-01	Gear shifter bracke			
52	1	1134-0267-00	Clamp plate			
53	1	1134-0266-00	Attaching clamp			
54	2	9997-0520-16	Screw			
55	2	9646-0036-22	Rivet			
56	2	9675-0008-02	Locking washer			
57	1	1131-1506-00	Spring			
59	1	1134-0240-00	Shoulder screw			
62	2	1134-1565-01	Spacer			
64	1	9600-0050-00	Key			
65	1	1134-2021-01	Clamp			
66	3	9699-0056-02	Flat washer			
67	1	1134-0269-00	Pedal rubber			
71	2	1134-2653-01	Nipple			
73	1	1134-2986-01	Bracket			
74	1	9959-0820-16	Screw			