



Section: PARK POWER TAKE-OFF

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1218					
	1258 1318 1418					
	1638 1358 1458					
	5219 5319 5419					
1	3	9739-0831-22	Nut			
2	1	1134-0143-00	Stop washer			
3	1	1134-2453-01	Locking pawl			
4	1	9695-0002-00	Washer			
5	1	1131-1497-01	Spring			
6	1	9646-0036-22	Rivet			
7	1	9675-0008-02	Locking washer			
8	1	1134-0027-01	Control lever			
9	1	1134-3573-01	Pto cable			
10	1	1134-1972-01	Disengaging lever			
11	2	9699-0025-02	Washer			
12	1	1134-0583-00	Plastic knob			
15	1	1134-0022-00	Control rod			
16	2	9672-0004-02	Lock washer			
17	1	1134-0153-00	Handle			
19	1	9847-8016-16	Screw			
23	1	4231-0013-00	Spring			
25	1	1134-1565-01	Spacer			
26	1	1134-1242-02	Spring			
27	1	1134-2018-01	Tensioning arm			
28	1	9997-1030-16	Screw			
29	1	1134-0054-01	Spacer			
30	1	1134-9027-01	Tension roller			
31	1	9799-1031-02	Nut			
32	1	1134-2020-01	Engine pulley			
33	1	9959-0820-16	Screw			
34	1	9997-0850-16	Screw			
35	1	9699-0056-02	Flat washer			
36	2	1134-0052-00	Bearing spacer			
37	1	1134-1769-02	Belt pulley assy			
38	2	9651-0040-04	.Retaining ring			
40	1	1134-0051-09	.Spacer			
41	2	9549-0019-00	.Ball bearing			
42	1	1134-0057-00	Centre shaft			
43	1	9699-0109-02	Flat washer			
44	1	1134-0222-00	Washer			
45	1	9959-1025-16	Screw			
46	1	1134-1730-01	Tension wheel arm			
47	2	1134-1888-01	Spacer			
48	1	1134-1770-01	Tension roller			
49	1	9549-0019-00	.Ball bearing			
50	1	9651-0040-04	.Retaining ring			
52	1	1134-1893-01	Spring attachment			
53	2	9699-0062-02	Flat washer			
54	1	9997-0865-12	Screw			
55	1	1134-1322-01	Spring			
56	1	9987-5332-16	Screw			
57	1	1134-9012-01	V-belt		= 9585-0056-00	
58	1	1134-9011-01	V-belt		= 9585-0054-00	
60	1	1134-3654-01	Finger guard		Tyskland	
61	2	9739-0631-22	Nut		Tyskland	
62	2	9959-0612-16	Screw		Tyskland	
91	1	9739-1031-22	Nut			
92	1	1134-0041-03	Collar			
93	1	9997-1070-12	Screw			