



Section: VILLA POWER TAKE-OFF

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		2816				
	2812	2836	2828			
	2832	2856	2858			
1	1	1	1	1134-1446-01	Spring	
2	1	1	1	1134-1866-01	Tensioning arm	
5	1	1	1	1134-9009-01	V-belt	= 9585-0052-00
6	1	1	1	1134-9027-01	Tension roller	
7	1	1	1	1134-0054-00	Spacer	
8	1	1	1	9739-1031-22	Nut	
12	1	1	1	1134-1569-01	Belt guide	
13	1	1	1	1134-9010-01	V-belt	= 9585-0053-00
14	1	1	1	1134-1935-01	Link rod	
16	1	1	1	1134-1023-00	Spring	
17	2	2	2	9699-0028-02	Flat washer	
18	1	1	1	1134-1438-02	Tensioning arm	
19	1	1	1	9699-0090-02	Flat washer	
20	1	1	1	9747-0831-02	Lock nut	
21	1	1	1	9696-0013-01	Bowed washer	
22	2	2	2	9699-0062-02	Flat washer	
23	3	3	3	9739-0831-22	Nut	
24	1	1	1	1134-1633-01	Engine belt pulley	
25	1	1	1	1134-0698-00	Tension roller assy	
26	1	1	1	9549-0017-00	.Ball bearing	
27	1	1	1	9651-0035-04	.Lock ring	
29	1	1	1	1134-1647-01	Belt stirrup	
32	1	1	1	1134-1839-01	Shaft	
33	1	1	1	9997-1080-12	Screw	
34	3	3	3	9699-0035-02	Flat washer	
35	1	1	1	9997-1035-16	Screw	
36	1	1	1	1134-1486-01	Double v-belt pulle	
37	1	1	1	1134-0051-07	.Spacer	
38	2	2	2	9651-0040-04	.Retaining ring	
39	2	2	2	9549-0019-00	.Ball bearing	
40	1	1	1	1134-1838-01	Bracket	
41	1	1	1	9997-0855-12	Screw	
42	1	1	1	9997-0840-16	Screw	
44	1	1	1	1134-1888-01	Spacer	
50	2	2	2	9672-0004-02	Lock washer	
51	1	1	1	1134-0022-00	Control rod	
52	2	2	2	9699-0025-02	Washer	
53	1	1	1	1134-0583-00	Plastic knob	
54	1	1	1	1134-1972-01	Disengaging lever	
55	1	1	1	9847-8016-16	Screw	
56	1	1	1	1134-0153-00	Handle	
58	1	1	1	9959-0820-16	Screw	
59	1	1	1	1134-3252-02	Seat bracket-yellow	
60	1	1	1	1134-0027-01	Control lever	
61	1	1	1	9675-0011-00	Starlock	
65	1	1	1	1131-1506-00	Spring	
66	1	1	1	1134-2453-01	Locking pawl	
67	1	1	1	1134-0143-00	Stop washer	
68	1	1	1	9695-0002-00	Washer	
69	1	1	1	1131-1497-01	Spring	