



## Section: VILLA TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		2816				
	2812	2836	2828			
	2832	2856	2858			
1	1	1	1	9987-5016-16	Screw	
2	1	1	1	9699-0060-02	Flat washer	
4	1	1	1	9500-9949-00	Transmission assy	
5	1	1	1	P000-7920-72	.Retaining ring	
6	1	1	1	P000-7861-14	.Sprocket	
7	1	1	1	9589-0008-02	Chain w. chain lock	
8	1	1	1	9589-0504-00	.Chain lock	
9	2	2	2	9997-0855-12	Screw	
10	2	2	2	1134-1561-01	Lever	
11	2	2	2	1134-1565-01	Spacer	
14	2	2	2	9739-0831-22	Nut	
15	4	4	4	9988-3619-16	Screw	
20	4	4	4	9795-3631-02	Nut	
21	1	1	1	1134-1691-02	Sprocket	
22	1	1	1	1134-1694-04	Differential assy	
24	1	1	1	1134-1936-01	Tensioning roller	
25	1	1	1	1134-1942-01	Adjusting screw	
26	1	1	1	9747-0831-02	Lock nut	
27	1	1	1	1134-1925-02	Gear shifter	
28	1	1	1	1134-1981-01	Shift lock	
29	1	1	1	1134-1916-01	Stop plate	
30	2	2	2	9942-0816-16	Screw	

test