



STIGA
173A
SPARE PARTS

Section: JB 521 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1119	1319				
1	1	1482-0484-01	Chain case assy			
2	1	1482-0480-01	.Oil drain plug			
2A	1	1482-0479-01	.Gasket			
3	2	1482-0214-01	.Oil-seal			
4	1	1482-0048-01	.Shaft			
5	2	1482-0485-01	.Needle bearing			
6	1	9589-1003-00	.Sprocket			
7	1	9915-1020-15	.Screw			
8	1	1482-0455-01	.Chain-lower			
10	1	9939-0860-12	.Screw			
11	5	9699-0028-02	.Flat washer			
12	2	9747-0831-02	.Lock nut			
13	4	1482-0473-01	.Needle bearing			
14	2	9660-0200-00	.Spacer			
15	2	1482-0452-01	.Spacer			
16	1	9589-1002-00	.Sprocket			
17	1	1482-0454-01	.Chain-middle			
20	1	1482-0453-01	.Plate			
21	1	1482-0451-01	.Sprocket			
22	1	9939-0850-12	.Screw			
23	2	1482-0456-01	.Washer			
25	1	1482-0450-01	.Chain-top			
26	2	1482-0458-01	.Seal			
27	2	1482-0459-01	.Lock ring			
28	2	9549-0017-00	.Ball bearing			
29	1	1482-0481-01	.Spacer			
31	1	9594-0015-00	.Locating pin			
32	1	9594-0055-00	.Locating pin			
33	1	1482-0482-01	.Spacer			
34	1	1482-0486-01	.Shaft w. gear			
35	1	1482-0438-01	Belt tensioner			
36	1	1482-0443-01	Gasket			
37	1	1482-0308-01	Cover			
38	1	1482-0248-01	Plastic plug			
39	2	9677-0006-02	Lock washer			
40	2	9997-0620-16	Screw			
45	1	9600-0016-00	Key			
46	1	1482-0439-01	Pulley			
47	2	9915-0810-15	.Set screw			
48	1	1482-9001-01	V-belt			
49	1	1482-9003-01	V-belt			
50	1	1482-0441-01	Pulley			
51	2	9915-0810-15	.Set screw			
52	1	1482-0040-01	Key			
55	1	1482-0465-01	Belt tensioner			
56	1	9997-0860-16	.Screw			
57	1	9678-0009-02	.Lock washer			
58	1	1482-0290-01	.Belt guide			
59	1	1482-0289-01	.Sleeve			
60	1	1482-0464-01	Spring			
61	1	9847-8016-16	Screw			
64	1	1482-9002-01	V-belt reverse			
65	1	1482-0437-01	Pulley			
66	2	9915-0606-15	.Set screw			
67	1	9600-0053-00	Key			
68	1	1482-0467-01	Belt guide			
69	1	1482-0466-01	Belt tensioner			
70	1	1482-0307-02	.Spring			
71	1	1482-0212-01	.Washer			
72	1	9650-0010-04	.Lock ring			
75	1	1482-0468-01	Flange			
76	2	9699-0028-02	Flat washer			
77	2	9683-0030-02	Lock washer			
78	2	9987-5119-16	Screw			
80	4	9997-0875-12	Screw			
81	4	9677-0009-02	Lock washer			

Section: JB 521 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1119	1319				
82	4	9799-0831-02	Nut			
85	2	1482-0052-01	Spacer			
90	2	1482-0435-01	Plate			
91	2	1482-0435-02	Plate			
92	4	9550-0002-00	Shock absorber			
93	16	9799-0831-02	Nut			
94	4	9997-0835-12	Screw			
95	4	9997-0825-16	Screw			
96	2	9699-0028-02	Flat washer			
97	1	1482-0417-01	Rotor guard			

test