

Section: GR 22 PETROL TRIMMER CYLINDER CRANKCASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1129					
5	1	1911-0867-01	Cylinder			
6	2	1911-0963-01	Screw			
7	1	1911-0866-01	Gasket			
8	1	1911-0471-02	Piston ring			
9	1	1911-0855-01	Piston			
10	1	1911-0857-01	Piston pin			
11	2	1911-0473-01	Circlip			
12	1	1911-0856-01	Needle bearing			
13	2	1911-0858-01	Spacer			
20	1	1911-0869-01	Cylinder cover			
21	6	1911-0966-01	Screw			
22	2	1911-0965-01	Screw			
23	1	1911-0962-01	Screw			
24	1	1911-0639-01	Spring washer			
25	1	1911-0637-01	Washer			
26	1	1911-0868-01	Fan cover			
27	2	1911-0863-01	Oil seal			
28	3	1911-0970-01	Screw			
29	1	1911-0862-01	Crankcase			
30	2	1911-0864-01	.Dowel pin			
31	2	1911-0644-02	Ball bearing			
32	1	1911-0865-01	Gasket			
33	1	1911-0859-01	Crankshaft			
34	1	1911-0860-01	Key			
37	2	1911-0912-01	Gasket			
38	1	1911-0913-01	Muffler cover			
40	1	1911-0915-01	Muffler			
41	1	1911-0914-01	Washer			
42	2	1911-0961-01	Screw			
43	1	1911-0917-01	Gasket			
44	1	1911-0916-01	Screen holder			
45	3	1911-0964-01	Screw			