



## Section: GR 22 PETROL TRIMMER FUEL SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1129					
5	1	1911-0910-01	Vent			
6	1	1911-0901-01	Clip			
7	1	1911-0911-01	Fuel pipe			
8	1	1911-0909-01	Fuel strainer			
10	1	1911-0906-01	Fuel tank			
11	2	1911-0754-01	Washer			
12	2	1911-0639-01	Spring washer			
13	2	1911-0971-01	Screw			
14	1	1911-0905-01	Fuel tank cap assy			
16	1	1911-0907-01	.Gasket			
17	1	1911-0946-01	Stand			
25	1	1911-0898-01	Gasket			
26	2	1911-0632-01	Nut			
27	2	1911-0969-01	Screw			
28	1	1911-0900-01	Insulator			
29	1	1911-0899-01	Gasket			
30	1	1911-0870-01	Carburettor assy			
31	1	1911-0902-01	Air cleaner case			
32	1	1911-0944-01	.Bushing			
33	1	1911-0943-01	Choke shutter			
34	2	1911-0585-01	Spacer			
35	2	1911-0630-01	Screw			
36	1	1911-0903-01	Air filter			
37	1	1911-0904-01	Fixture air cleaner			

test