



## Section: MULTICLIP

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		3211	3237	3225	3233		
1	1	1	1	1	1111-1603-01	Blade bar assy	
2	1	1	1	1	1111-9049-01	.Blade kit	
3	2	2	2	2	9997-0816-16	..Screw	
4	2	2	2	2	9747-0831-02	..Lock nut	
6	1	1	1	1	9987-5238-12	Blade bolt	
7	1	1	1	1	9696-0011-01	Washer	
10	1	1	1	1	1111-9054-01	Blade holder assy	
11	1	1	1	1	9600-0014-00	Key	
17	4	4	4	4	1111-2656-01	Wheel	
18	2	2	2	2	1111-1589-02	.Height adj.spring-	
18	1	1	1	1	1111-9035-01	Height adjust kit	
19	2	2	2	2	1111-1589-01	.Height adj.spring-	
20	1	1	1	1	1111-9042-01	.Wheel lock kit	
20	4	4	4	4	9675-0017-02	..Lock washer	
21	4	4	4	4	9699-0069-02	Flat washer	
22	2	2	2	2	1111-1590-01	Wheel axle	
23	4	4	4	4	1111-1335-01	Hub cap	
25	3	3	3	3	9699-0056-02	Flat washer	
26	3	3		3	9997-0830-16	Screw	30 mm
26			2		9997-0835-12	Screw	35 mm
26			1		9997-0860-16	Screw	60 mm
27	3	3	3	3	9683-0030-02	Lock washer	
28	3	3	3	3	9799-0831-02	Nut	
31	1	1	1	1	1111-3017-01	Handlebar clamp	
32	1	1	1	1	1111-1532-01	Pivot rod	
33	2	2	2	2	9670-0203-00	Lock washer	
34	1	1	1	1	1111-9030-02	Handle bolt kit	
34	2	2	2	2	1111-0035-01	.Locking knob	
36	2	2	2	2	9699-0025-02	.Washer	
37	2	2	2	2	9899-3545-12	.Screw	
38	1	1	1	2	1111-2018-01	Cable holder	
39	1	1	1	2	9836-9216-12	Screw	
40	1	1	1	1	1111-1702-01	Handlebar-lower par	
41	1	1	1	1	1111-2005-01	Handlebar-upper par	
44	2	2	2	2	1111-1529-01	Side guard	
46	1	1	1	1	1111-1881-01	Chassis	
48	1		1		1111-2366-01	Gas control	
48		1		1	1111-2367-04	Gas control	
50	2	2	2	2	9747-0631-02	Lock nut	
51	2	2	2	2	9948-0645-16	Screw	
67	1	1	1	1	1111-2375-01	Spring	
70				2	9836-9540-12	Screw	
71				1	9836-9216-12	Screw	
72				1	1111-2020-01	Housing	
73				1	1111-2021-01	Cover	
74				1	9400-0186-00	Starting switch ass	
75				1	1134-2848-01	.Ignition key	
76				1	1111-2024-03	Wire harness	
77				1	1111-2392-01	Battery plate	
78				2	9403-0040-00	Rubber plug	
79				2	9943-0612-16	Screw	
80				1	9400-0218-00	Battery	
81				1	9400-0219-00	Charger	
99	1				1111-2233-02	Decal kit	