



STIGA
182A
SPARE PARTS

Section: TRANSMISSION TURBO 460S-510S-510SE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6216	7222				
	6516	7522	7339			
	6535	7538	7639			
0	1		1111-1186-01		Transmission assy.	
0	1	1	1111-2255-01		Transmission assy	
1	2	2	9659-0050-04		.Lock ring	
2	1	1	F000-4020-00		.Housing, upper, fi	
3	4	4	F000-3035-00		.Screw	
4	1	1	F000-3346-00		.Screw	
5	1	1	F000-3574-00		.Washer, flanged	
6	1	1	F000-3090-00		.Lever, clutch	
7	ERF	ERF	ERF		F000-3194-00 .Washer, plain	25 x 13 x 0.5 mm
7	ERF	ERF	ERF		F000-1544-00 .Washer, plain	19 x13 x 0.4 mm
7	ERF	ERF	ERF		F000-3121-00 .Washer, plain	24 x 13 x 0.7 mm
8	1	1	F000-3584-00		.Shaft, worm input	
9	1	1	F000-3475-00		.Key	
10	1	1	F000-3095-00		.Gasket	
11	1	1	F000-2720-00		.Housing, lower	
14	2	2	F000-3278-00		.Pin, spring	
15	1	1	F000-3082-00		.Key	
16	1		F000-3480-00		.Shaft, output	
16	1	1	F000-3985-00		.Shaft, output	
17	1	1	F000-1599-00		.Washer, plain	
20	2	2	F000-2711-00		.Bearing & seal	
21	1	1	F000-3121-00		.Washer, plain	
22	1	1	F000-4013-00		.Kit, gear & clutch	
23	1	1	F000-3194-00		.Washer, plain	
35	1	1	1111-1843-01		Special grease	

test