



Section: TURBO 35 EL CHASSIS

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	3762	3763	3862	3867			
1	1	1	1	1	1111-1310-01	Blade bar assy	
2	1	1			1111-9046-01	.Blade kit	
2			1	1	1111-9504-01	.Blade kit	
3	2	2	2	2	9997-0812-16	..Screw	
4	2	2	2	2	9747-0831-02	..Lock nut	
6	1	1	1	1	1111-0572-00	Blade bolt	
7	1	1	1	1	1111-1419-01	Blade wrench	
8	1	1	1	1	1111-1309-01	Blade holder	
10	4	4	4	4	9997-0816-16	Screw	
11	4	4	4	4	9699-0090-02	Flat washer	
12	2	2	2	2	9836-9512-12	Screw	
13	1	1	1	1	1111-1290-01	Motor housing	
15	1	1	1	1	9579-0007-00	Cord restrainer	
16	2	2	2	2	9849-7819-16	Screw	
17	1	1	1	1	9600-0132-00	Flat key	
18	1	1	1	1	9500-1100-00	Electric motor	
19	1	1	1	1	9400-0166-00	.Condensor	
20	1	1	1	1	1111-1396-01	Indicator	
21	1	1	1	1	1111-1384-01	Motor casing-black	
22	2	2	2	2	9849-7819-16	Screw	
23	2	2	2	2	9699-0002-02	Flat washer	
25	1	1	1	1	1111-1294-01	Chassis	
26	1	1	1	1	1111-1296-01	Attachment	
27	2	2	2	2	9836-9512-12	Screw	
28	2	2	2	2	9840-8019-16	Screw	
30	1	1	1	1	1111-1298-01	Pivot pin	
31	2	2	2	2	9672-0005-02	Starlock	
32	2	2	2	2	1111-1300-01	Spring holder	
33	1	1	1	1	1111-1299-01	Spring	
34	1	1	1	1	1111-1297-01	Flap	
35		1			1111-1453-01	Protection	Finland (FIN)
37	1	1	1	1	1111-1315-01	Front piece	Ej 3862-55
38	2	2	2	2	9865-0510-16	Screw	Ej 3862-55
39	2	2	2	2	9699-0099-02	Washer	Ej 3862-55
40	2	2	2	2	9747-0531-02	Nut	Ej 3862-55
42	1	1	1	1	1111-1314-01	Collecting bag	Ej 3862-55
43	10	10	10	10	9845-7913-16	Screw	Ej 3862-55
45	1	1	1	1	1111-1392-01	Handle	Ej 3862-55
46	2	2	2	2	9403-0034-70	.Plastic knob	
47	1	1	1	1	9403-0033-70	.Plastic knob	
48	1	1	1	1	9839-8013-16	Screw	Ej 3862-55
50	1	1	1	1	1111-1295-01	Guide bar	
51	1	1	1	1	9836-9516-12	Screw	
52	2	2	2	2	9836-9520-12	Screw	
54	1	1	1	1	1111-1411-01	Protection	
55	4	4	4	4	9836-9512-12	Screw	
99	1	1			1111-2233-06	Decal kit	