



STIGA
182A
SPARE PARTS

Section: TRANSMISSION TURBO 460-510

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

460 510

0		1	1111-2255-01	Transmission assy		
0	1		1111-1186-01	Transmission assy.		
1	2	2	9659-0050-04	.Lock ring		
2	1	1	F000-4020-00	.Housing, upper, fi		
3	4	4	F000-3035-00	.Screw		
4	1	1	F000-3346-00	.Screw		
5	1	1	F000-3574-00	.Washer, flanged		
6	1	1	F000-3090-00	.Lever, clutch		
7	ERF	ERF	F000-1544-00	.Washer, plain	19 x 13 x 0.4 mm	
7	ERF	ERF	F000-3121-00	.Washer, plain	24 x 13 x 0.7 mm	
7	ERF	ERF	F000-3194-00	.Washer, plain	25 x 13 x 0.5 mm	
8	1	1	F000-3584-00	.Shaft, worm input		
9	1	1	F000-3475-00	.Key		
10	1	1	F000-3095-00	.Gasket		
11	1	1	F000-2720-00	.Housing, lower		
14	2	2	F000-3278-00	.Pin, spring		
15	1	1	F000-3082-00	.Key		
16	1		F000-3480-00	.Shaft, output		
16		1	F000-3985-00	.Shaft, output		
17	1	1	F000-1599-00	.Washer, plain		
20	2	2	F000-2711-00	.Bearing & seal		
21	1	1	F000-3121-00	.Washer, plain		
22	1	1	F000-4013-00	.Kit, gear & clutch		
23	1	1	F000-3194-00	.Washer, plain		
35	1	1	1111-1843-01	Special grease		

test