



TIGA
374
SPARE PARTS

Section: JB 30

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1112					
1	4	9997-0845-12	Screw			
2	4	9683-0030-02	Lock washer			
3	4	9699-0028-02	Flat washer			
4	4	9799-0831-02	Nut			
6	1	1482-0493-01	Belt tensioner assy		Inkl.pos. 8,12-16	
7	1	1482-0494-01	Sleeve			
9	1	9699-0028-02	Flat washer			
10	1	9683-0030-02	Lock washer			
11	1	9987-5125-16	Screw			
12	1	9799-1031-02	.Nut			
15	1	9683-0040-02	.Lock washer			
16	1	9997-1025-16	.Screw			
17	2	9915-0606-15	.Set screw			
18	1	1482-0488-01	Belt pulley		Inkl.pos. 17	
19	1	1482-0040-01	Key			
20	1	9794-5131-02	Nut			
21	1	1482-0464-01	Spring			
22	1	9987-5119-16	Screw			
23	1	1482-0495-01	Handlebar			
24	1	1482-0301-01	Bracket			
25	2	1482-0528-01	Grip			
26	1	1482-0525-01	Rivet			
27	1	1482-0445-01	Grip			
28	1	1482-0487-01	.S-hook			
29	1	1482-0444-01	Chain w hook		Inkl.pos. 28	
30	1	1482-0250-01	Spring			
31	1	9799-0631-02	Nut			
32	1	9683-0025-02	Lock washer			
33	1	1482-0635-01	Throttle control			
34	1	9997-0645-12	Screw			
35	1	1482-0496-01	Clutch cable			
36	1	9997-0640-12	Screw			
37	1	9683-0025-02	Lock washer			
38	1	9799-0631-02	Nut			
39	1	9997-0812-02	Screw			
40	1	9699-0028-02	Flat washer			
41	1	9699-0028-02	Flat washer			
42	1	9683-0030-02	Lock washer			
43	1	9751-0821-02	Wing nut			
44	1	1482-0497-01	Handle tube			
45	1	1482-0497-01	Handle tube			
46	2	9751-0631-02	Wing nut			
47	2	9898-0635-12	Screw			
48	1	9997-0616-16	Screw			
49	1	9699-0025-02	Washer			
50	1	9683-0025-02	Lock washer			
51	1	9799-0631-02	Nut			
52	1	1482-0498-01	Bracket			
53	1	1482-0041-00	Cotter bolt			
54	1	9598-0002-02	Pin lock			
55	1	9405-0101-00	Ring			
56	1	1482-0499-01	Depth control			
57	2	9997-0616-16	Screw			
58	2	9683-0025-02	Lock washer			
59	2	9799-0631-02	Nut			
60	1	1482-0500-01	Mud guard-R.H.			
61	1	1482-0502-01	Side brace-R.H.			
62	2	1482-0501-01	Spacer			
63	1	1482-0248-01	Plastic plug		Inkl.pos. 64	
65	4	9799-0631-02	Nut			
66	4	9683-0025-02	Lock washer			
67	4	1482-0503-01	Bushing			
68	4	1482-0503-01	Bushing			
69	4	9997-0640-12	Screw			
70	1	1482-0524-01	Gear housing assy		Inkl.pos. 71-92	
71	1	1482-0504-01	.Housing half-R.H.			

Section: JB 30

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1112					
72	1	1482-0505-01	.Spring			
73	1	1482-0506-01	.Chain tensioner			
74	1	9549-0003-00	.Ball bearing			
76	1	1482-0508-01	.Shaft w/sprocket			
77	1	1482-0509-01	.Bushing			
78	1	1482-0510-01	.Housing half-L.H.			
79	1	9549-0003-00	.Ball bearing			
80	1	1482-0459-01	.Lock ring			
81	1	1482-0458-01	.Seal			
82	1	1482-0511-01	.Gasket			
83	1	1482-0214-01	.Oil-seal			
84	1	1482-0485-01	.Needle bearing			
85	1	1482-0512-01	.Spacer ring			
86	1	1482-0513-01	.Shaft-outer			
87	1	1482-0514-01	.Chain			
88	1	1482-0512-01	.Spacer ring			
89	1	1482-0485-01	.Needle bearing			
90	1	1482-0214-01	.Oil-seal			
91	24	9799-0531-02	.Nut			
92	24	9997-0510-16	.Screw			
93	1	1482-9001-01	V-belt			
94	2	9915-0808-15	.Set screw			
95	1	1482-0016-02	Pulley		Inkl.pos. 94	
96	1	9600-0016-00	Key			
97	1	1482-0515-01	Side brace-L.H.			
98	1	1482-0516-01	Belt guard retainer			
99	1	9683-0025-02	Lock washer			
100	1	9751-0631-02	Wing nut			
101	1	9799-0631-02	Nut			
102	1	9699-0025-02	Washer			
103	1	9683-0025-02	Lock washer			
104	1	9997-0616-16	Screw			
105	1	1482-0517-01	Mud guard-L.H.			
106	1	1482-0229-01	Spacer			
107	1	1482-0199-01	Belt guard extensio			
108	1	9683-0030-02	Lock washer			
109	1	9987-5189-12	Screw			
110	1	1482-0149-01	Cover			
111	1	1482-0223-05	Belt guard			
112	1	1482-0667-01	Handle			
113	2	9799-0631-02	Nut			
114	2	9683-0025-02	Lock washer			
115	2	9997-0616-16	Screw			
117	1	1482-0520-01	Wheel fork			
118	2	9799-1031-02	Nut			
119	2	9683-0040-02	Lock washer			
120	2	1482-0526-01	Wheel			
121	2	1482-0521-01	Wheel bushing			
122	2	9699-0035-02	Flat washer			
123	2	9997-1060-12	Screw			
124	1	9598-0002-02	Pin lock			
125	1	1482-0523-01	Spring			
126	1	1482-0522-01	Wheel fork lock			
127	1	9699-0035-02	Flat washer			
128	32	9987-5222-16	.Screw			
129	32	9794-5231-02	.Nut			
130	8	1482-0490-01	.Blade-L.H.			
131	2	1482-0519-01	.Rotor tube			
132	8	1482-0489-01	.Blade-R.H.			
133	2	9598-0002-02	.Pin lock			
134	2	1482-0041-00	.Cotter bolt			
135	1	1482-0491-01	Rotor assy-R.H.		Inkl.pos. 128-134	
136	1	1482-0492-01	Rotor assy-L.H.		Inkl.pos. 128-134	
138	2	9997-0635-12	Screw			
139	2	9683-0025-02	Lock washer			
140	2	9799-0631-02	Nut			

Section: JB 30

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1112					
141	2	9683-0025-02	Lock washer			

test