



test



Section: 4000-4500 EL.TRIMMER

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1135	1145				
1	1	1	1911-0704-02		Connection cable	
2	1	1	1911-0977-01		Grommet	
3	1	1	1911-1001-01		Switch	
4	1	1	1911-1012-01		Condensor	
5	1	1	1911-1013-01		Internal cable	
6	1	1	1911-0983-01		Handle housing	
7	1	1	1911-0980-01		Helpers handle	
8	1	1	1911-0994-01		.Screw	
10	5	5	1911-0997-01		Screw	
11	2	2	1911-0995-01		Locking knob	
12	1	1	1911-0998-01		Screw	
13	1	1	1911-0982-01		Motor housing	
15	7	7	1911-0996-01		Screw	
16	1		1911-1008-01		Protection cover	
16		1	1911-0986-01		Protection cover	
17	4	2	1911-0822-01		Screw	
18		2	1911-1009-01		Screw	
19	1		1911-1004-01		Motor (not stocked)	
19		1	1911-1005-01		Motor (not stocked)	
20	1	1	1911-0984-01		Motor plate	
21	2	2	1911-0824-01		Screw	
25	1		1911-0850-01		Cutting head assy	
26	1		1911-0851-02		.Drive plate	
27	1		1911-0852-01		.Spring	
28	1		1911-9004-01		.Spool w.line	
29	1		1911-9005-07		Cutting line (1.2 m	8 m
29	1		1911-9005-08		Cutting line (1.2 m	15 m
29	1		1911-9005-04		Cutting line (1.2 m	Kassett 0,225 kg
30	1		1911-0725-02		.Head cap	
35		1	1911-0987-01		Duo-line cuttinghea	
36		1	1911-0988-01		.Drive plate	
37		1	1911-0989-01		.Spring	
38		1	1911-1007-01		.Duo-spool w.line	
39	1		1911-9005-07		Cutting line (1.2 m	8 m
39	1		1911-9005-08		Cutting line (1.2 m	15 m
39	1		1911-9005-04		Cutting line (1.2 m	Kassett 0,225 kg
40		1	1911-0990-01		.Ring	
41		1	1911-0991-01		.Head cap	
46		1	1911-1000-01		Glide sledge	
47		1	1911-0999-01		Roller holder	
48		1	1911-0992-01		Roller	
49		1	1911-0993-01		Ring	