



## Section: GARDEN ENGINE TRANSMISSION

Pos.	Quantity					Spare part No	Description	Kit	Notes	New
		2322	2328							
	2321	2324	2326	2329						
1	1	1	1	1	1134-3090-01	Fuel tank				
2	1	1	1	1	1134-2877-02	Fuel tank cap				
3	1	1	1	1	1134-3224-01	Fuel shut-off valve				
4	1	1	1	1	1134-3225-01	Grommet				
5	1	1	1	1	1134-3221-01	Fuel tank support				
6	6	6	6	5	9747-0831-02	Lock nut				
7	1	1	1	1	1134-3185-01	Engine belt pulley				
7	1	1	1	1	9997-1450-16	Puller-belt pulley				
8	1	1	1	1	1134-3141-01	Clutch lever				
9	2	2	2	2	1134-3144-01	Plastic spacer				
10	5	5	5	5	9849-8013-16	Screw				
11	2	2	2	2	1134-0240-00	Shoulder screw				
12	3	3	3	3	1134-3147-01	Plastic washer				
13	3	3	3	3	9699-0056-02	Flat washer				
14	9	8	10	10	9739-0831-22	Nut				
15	1	1	1	1	1134-9027-01	Tension roller				
16	1	1	1	1	9739-1031-22	Nut				
17	1	1	1	1	1134-9013-01	V-belt		=9585-0057-00		
18	1	1	1	1	1134-1578-01	Spring				
19	1	1	1	1	1134-2086-01	Belt stirrup				
20	1	1	5	5	9997-0830-16	Screw				
21	1	1	1	1	1134-3157-01	Transaxle assy				
22	1	1	1	1	1134-3154-01	Spacer tube				
23	1	1	1	1	9997-0815-02	Screw				
24	2	1	1	1	9699-0090-02	Flat washer				
25	1	1	1	1	1134-3182-01	Belt pulley				
26	1	1	1	1	9600-0050-00	Key				
27	1	1	1	1	9650-0016-04	Lock ring				
28	1	1	1	1	1134-3106-01	Pedal bracket				
29	2	2	2	2	9898-0820-16	Screw				
30	1	1	1	1	1111-0062-01	Control lever				
31	1	1	1	1	1111-0040-02	Control knob				
32	1	1	1	1	9694-0001-00	Washer				
33	1	1	1	1	1134-1597-09	Gas wire				
34	1	1	1	1	1134-3240-01	Wire clamp				
35	1	1	1	1	1134-3112-02	Gear shifter				
36	1	1	1	1	1134-3193-01	Lever handle				
37	1	1	1	1	1134-1565-01	Spacer				
38	2	2			9997-0845-12	Screw				
39	1	1	1	1	1134-3160-01	Gear shifter plate				
40	2	2	2	2	9675-0012-02	Locking washer				
41	1	1	1	1	1134-3109-01	Gear shifter lever				
42	1	1	1	1	9987-5016-16	Screw				
43	1	1	1	1	9699-0060-02	Flat washer				
44	1	1	1	1	1134-3169-01	Brake/clutch pedal				
45	1	1	1	1	1134-0269-00	Pedal rubber				
46	1	1	1	1	1111-0158-00	Bushing				
47	1	1	1	1	1134-3047-01	Spacer				
48	1	1	1	1	4231-0013-00	Spring				
49	1	1	1	1	1134-3146-01	Control rod				
50	1	1	1	1	9599-0067-02	Cotter pin				
51	1	1	1	1	9598-0002-02	Pin lock				
52	1	1	1	1	1134-3178-01	Plastic housing				
53	1	1	1	1	1134-3179-01	Parking brake lever				
54	1	1	1	1	1134-3180-01	Compression spring				
55	3	3	3	3	9997-0520-16	Screw				
56	3	3	3	3	9747-0531-02	Nut				
57	1	1	1	1	9987-5338-12	Screw				
58	2	2	2		9842-0001-16	Screw				
59	1	1	1		1134-3206-01	Muffler deflector				
60	4	4			1134-3113-02	Spacer				
61	2	2			9988-3625-16	Screw				
62	1	1	1	1	9600-0250-00	Key				
63	1				1134-3282-01	Starter rope holder				
64	1				9997-0840-16	Screw				
65			1	1	1134-2212-01	Oil drain pipe assy				

## Section: GARDEN ENGINE TRANSMISSION

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		2322		2328					
		2321	2324	2326	2329				
66			1	1		1134-0995-01	.Plug		
67			1	1		9404-0020-00	.O-ring		
68			1	1		1134-0997-01	.Fibre gasket		
69	1	1				1134-2483-02	Oil drain pipe		
70	1	1				1134-0995-02	.Plug		
71	1	1				1134-0997-02	.Fibre gasket		
72	1	1				9404-0022-00	.O-ring		
73	2	2	2	2		1134-3171-01	Rim		
74	2	2	2	2		9545-0118-00	Tyre	15 x 6.00-6	
74						9545-0210-00	Inner tube	Reservdel/spare par	
75	2	2	2	2		9545-0500-00	Valve		
76	2	2	2	2		1134-3170-01	Bolt		
77	1	1	1	1		1134-3200-01	Shift rod		
78	1	1				1134-0149-00	Spacer		
80	1	1	1	1		9997-0855-12	Screw		
82				1		1134-2975-04	Fuel line		
83				2		9578-0016-00	Clamp		
83				1		222902	Deflector	B&S-part	
83				1		491413	Muffler	B&S-part	
83				2		93705	Screw	B&S-part	

test