



Section: VILLA STEERING SEAT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
1	1	1134-2390-01	Steering wheel			
2	1	9595-0262-00	.Locating pin			
3	1	9699-0103-02	.Flat washer		0,5 mm	
3	1	9699-0114-02	.Flat washer		1,0 mm	
4	1	9595-0262-00	Locating pin			
5	1	1134-1424-01	Steering column			
6	2	1134-1901-01	Bearing			
8	1	1134-1933-01	Steering pulley			
9	4	1134-0041-01	Bushing			
10	2	1134-9025-01	Steering pulley-kit			
11	3	1134-3022-01	Cable holder			
12	4	9942-1030-16	Screw			
13	1	1134-9023-01	Steering wire			
14	5	9747-0831-02	Lock nut			
15	1	9699-0090-02	Flat washer			
16	1	1134-1310-01	Compression spring			
17	5	9959-0816-16	Screw			
18	4	9739-0831-22	Nut			
19	1	1134-9024-01	Bearing			
20	1	1134-0341-01	Washer			
21	1	9650-0020-04	Circlip			
23	1	1134-1500-02	Steering pulley			
25	2	1134-3247-02	Tie rod			
30	1	9959-0825-16	Screw			
32	1	1134-0022-00	Control rod			
33	2	9672-0004-02	Lock washer			
34	1	1134-2163-01	Rod			
35	1	1134-2166-01	Spacer			
42	1	1134-3252-02	Seat bracket-yellow			
43	1	1134-2846-01	Tube			
44	1	1134-1883-01	Axle			
45	1	1134-0015-00	Seat spring			
48	1	1134-1652-01	Spring shackle			
49	1	1134-0050-00	Seat rod			
50	1	1134-0493-00	Spring nut			
52	2	1134-1650-01	Tie bar			
53	4	9675-0017-02	Lock washer			
54	2	1134-2961-01	Seat adapter			
55	2	9898-0820-16	Screw			
56	4	9988-3616-16	Screw			
57	2	9699-0062-02	Flat washer			
58	2	1134-1711-01	Knob			
63	1	1134-3618-01	Seat bracket-R.H.			
64	1	1134-3618-02	Seat bracket-L.H.			
65	1	1134-0800-06	Seat			
65	1	1134-2541-01	Seat		Tyskland-Villa 11E	
67	1	1134-2454-01	Shaft			
68	2	9672-0006-02	Lock washer			
69	1	1134-2847-01	Shaft			
70	1	1134-3022-01	Cable holder			
71	2	9699-0028-02	Flat washer			
72	4	9997-0825-16	Screw			