



Section: MULTICLIP

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			3213				
	3213	3213	-57	3513			
	-17	-37	-97	-57			
1	1	1	1	1111-1603-01	Blade bar assy		
2	1	1	1	1111-9049-01	.Blade kit		
3	2	2	2	9997-0816-16	..Screw		
4	2	2	2	9747-0831-02	..Lock nut		
6	1	1	1	9987-5238-12	Blade bolt		
7	1	1	1	9696-0011-01	Washer		
10	1	1	1	1111-9023-02	Blade holder		
11	1	1	1	9600-0014-00	.Key		
17	4		4	1111-2656-01	Wheel		
18	2	2	2	1111-1589-02	.Height adj.spring-		
18	1	1	1	1111-9035-01	Height adjust kit		
19	2	2	2	1111-1589-01	.Height adj.spring-		
20	1	1	1	1111-9042-01	.Wheel lock kit		
20	4	4	4	9675-0017-02	..Lock washer		
21	4		4	9699-0069-02	Flat washer		
22	2	2	2	1111-1590-01	Wheel axle		
23			4	1111-1335-01	Hub cap		
24	4	4		1111-2657-01	Hub cap-yellow		
25	4	4		1111-2675-01	Wheel cup-yellow		
26	3	3	3	9997-0830-16	Screw	30 mm	
27	3	3	3	9683-0030-02	Lock washer		
28	3	3	3	9799-0831-02	Nut		
31	1	1	1	1111-3017-01	Handlebar clamp		
32	1	1	1	1111-1532-01	Pivot rod		
33	2	2	2	9670-0203-00	Lock washer		
34	1	1	1	1111-9030-02	Handle bolt kit		
34	2	2	2	1111-0035-01	.Locking knob		
36	2	2	2	9699-0025-02	.Washer		
37	2	2	2	9899-3545-12	.Screw		
38	1	1	1	1111-2018-01	Cable holder		
39	1	1	1	9836-9216-12	Screw		
40	1	1	1	1111-1702-01	Handlebar-lower par		
41	1	1	1	1111-2005-01	Handlebar-upper par		
44	2	2	2	1111-1529-02	Side guard-yellow		
45			4	1111-1593-01	Washer		
46	1	1	1	1111-2982-01	Chassis-yellow		
48	1	1	1	1111-2366-01	Gas control		
50	2	2	2	9747-0631-02	Lock nut		
51	2	2	2	9948-0645-16	Screw		
57		4		1111-2784-01	Wheel assy		
58		1		1111-9047-01	.Ball bearing kit		
59		2		1111-1184-01	..Bearing cone		
60		4		1111-1138-01	Spring		
63			1	1111-0931-02	Mounting bar		
64			1	1111-0932-01	Mounting bar		
65			1	1111-0933-02	Rubber guard		
66			4	1151-0300-01	Rivet		
67	1	1	1	1111-2375-01	Spring		
77			1	223611	Heat guard	B&S-part	
78			1	223600	Heat plate	B&S-part	
79			7	93705	Screw	B&S-part	
99	1	1		1111-2893-02	Decal kit		