



## Section: TORNADO REAR WHEEL SUSPENSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

					4318	
	4215	4414	4719			
14	2			1111-1181-01	Hub cap	4215-51, 4215-91
15	2	2	2	9699-0037-02	Washer	
16	2	2	2	1111-2183-01	Spring	
17	2	2		1111-2782-01	Wheel cover	
18	2	2		1111-2665-01	Wheel assy	
19	1	1		1111-9047-01	.Ball bearing kit	
20	2	2		1111-1184-01	..Bearing cone	
21	2	2	2	9699-0100-02	Washer	
22	2	2	2	9997-0612-16	Screw	
23	2	2		1111-2664-01	Hub cap	4215-11
24	2	2		1111-2676-01	Wheel cup	4215-11
25			2	1111-2077-01	Hub cap	
26			2	1111-2247-01	Wheel w/o bearing	
27			4	9549-0001-00	Ball bearing	
28			2	1111-2141-01	Cover plate	
30	2	2	2	9943-0610-16	Screw	
31	2	2	2	1111-2653-01	Wheel cleaner	
32	6	6	6	9836-9516-12	Screw	
33	2	2	2	1111-2741-01	Clamp	
34	1	1	1	1111-2586-01	Rear axle	
35	1	1	1	1111-1074-01	Spring-height adjus	
36	1	1	1	9997-0816-16	Screw	
37	2	2	2	9675-0011-00	Starlock	
38	1	1	1	9739-0831-22	Nut	
39	1	1	1	1111-2597-01	Tension rod	
40	1	1	1	1111-2593-01	Lever	
43	2	2	2	9699-0025-02	Washer	
65	1	1	1	1111-2578-01	Height adj. quadrant	
66	2	2	2	9848-8013-16	Screw	
67	1	1	1	9799-0831-02	Nut	
68	1	1	1	9403-0036-70	Lever knob	
69	1	1	1	1111-2577-01	Baffle	
70	7	7	7	9836-9512-12	Screw	