



Section: PARK 18HST EL. LIFTING DEVICE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1818					
	1448					
1	1	1134-3305-03	Stand			
2	1	1134-9024-01	Bearing		Sats 4 st/kit of 4	
3	1	1134-3317-01	Shaft			
4	1	9595-0210-00	Locating pin			
5	1	1134-3309-01	Lever			
6	1	1134-3310-01	Lift arm			
7	1	1134-3313-01	Shaft			
8	2	9595-0280-00	Locating pin			
9	1	1134-3320-01	Lift lever			
10	1	9959-1025-16	Screw			
11	1	9747-1031-02	Lock nut			
12	1	1134-3314-01	Lift cylinder			
13	1	1134-3714-01	Switch box			
14	4	9950-0510-16	Screw			
15	4	9747-0531-02	Nut			
16	1	1134-3331-01	Hour meter			
17	4	1134-2857-01	Switch			
18	1	1134-2902-01	Symbol plate-green		Farthåll/cruise con	
19	1	1134-3329-01	Symbol plate-red			
19	1	1134-3329-02	Symbol plate-orange			
20	1	1134-2902-02	Symbol plate-green		Krafttutttag/PTO	
22	1	1134-3690-01	Harness			
23	1	1134-3203-04	Cable protector			
24	1	1134-3647-01	Tubing			
25	2	9959-1020-16	Screw			
26	2	9739-1031-22	Nut			
27	2	9699-0037-02	Washer			
28	2	9599-0083-02	Split pin			
29	2	9400-0231-00	Splicer			
31	4	9579-0003-00	Cable holder			
34	2	9400-0238-00	Cable connection			
36	1	1134-3332-01	Female terminal			
37	3	9865-0530-16	Screw			
38	3	9747-0531-02	Nut			
39	1	1134-3203-02	Grommet			
42	1	1134-3652-01	Plug			
43	1	1134-3646-01	Connecting plug			
44	1	1134-3691-01	Connecting plug			
45	1	1134-3692-01	Terminal plug			
46	1	1134-3693-01	Terminal plug			