



Section: PARK SEAT

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		1171							
		1172							
		1168	1358	1458	1818				
		1442	1443	1446	1448				
1	1	1	1			1134-2541-01	Seat	1168,1171,1172,1446	
1			1	1		1134-3286-01	Seat	1458	
1	1					1134-0800-06	Seat	1442	
2	2	2	2	2		1134-2961-01	Seat adapter		
3	2	2	2	2		9898-0820-16	Screw		
4	4	4	4	4		9988-3616-16	Screw		
5	4	4	4	4		9675-0017-02	Lock washer		
6	1	1	1	1		1134-3618-01	Seat bracket-R.H.		
10	1	1	1	1		1134-3618-02	Seat bracket-L.H.		
11	2	2	2	2		9699-0062-02	Flat washer		
12	2	2	2	2		1134-1711-01	Knob		
13	1	1	1	1		1134-1652-01	Spring shackle		
14	1	1	1	1		1134-0050-00	Seat rod		
18	2	2	2	2		1134-1650-01	Tie bar		
20	1	1	1	1		1134-0493-00	Spring nut		
21	1	1	1	1		1134-0015-00	Seat spring		
22	2	2	2	2		9799-0831-02	Nut		
28	1	1	1	1		1134-2846-01	Tube		
30	1	1	1	1		1134-1883-01	Axle		
31	1	1	1	1		1134-0022-00	Control rod		
32	2	2	2	2		9672-0004-02	Lock washer		
36	1	1	1	1		1134-2163-01	Rod		
37	1	1	1	1		1134-2166-01	Spacer		
48	1	1	1	1		1134-2454-01	Shaft		
49	2	2	2	2		9672-0006-02	Lock washer		
50	1	1	1	1		1134-2847-01	Shaft		
97				1		..13-1962-11	Arm rest		
98				2		9988-3619-16	.Screw	5/16"	
98				2		9988-3719-16	.Screw	3/8"	
99				2		9699-0028-02	.Flat washer		

