



Section: VILLA SEAT

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			2858 2859				
			2855 2870 2881				
			2812 2854 2842 2843				
1	1	1	1	1	1134-0015-00	Seat spring	
2	1	1	1	1	1134-0493-00	Spring nut	
3	1	1	1	1	1134-2846-01	Tube	
4	1	1	1	1	1134-2847-01	Shaft	
5	1	1	1	1	1134-0022-00	Control rod	
6	1	1	1	1	1134-0050-00	Seat rod	
7	2	2	2	2	1134-1650-01	Tie bar	
8	1	1	1	1	1134-1652-01	Spring shackle	
9			1	1	1134-1685-03	Seat bracket-R.H.	USA, Canada
9	1	1	1	1	1134-3618-01	Seat bracket-R.H.	
10			1	1	1134-1685-04	Seat bracket-L.H.	USA, Canada
10	1	1	1	1	1134-3618-02	Seat bracket-L.H.	
11	1	1	1	1	1134-1883-01	Axle	
12	1	1	1	1	1134-2163-01	Rod	
13	1	1	1	1	1134-2166-01	Spacer	
14	1	1	1	1	1134-2454-01	Shaft	
15	2	2	2	2	9672-0006-02	Lock washer	
16	2	2	2	2	9672-0004-02	Lock washer	
17	4	4	4	4	9675-0017-02	Lock washer	
18	2	2	2	2	9799-0831-02	Nut	
30	1	1			1134-0800-06	Seat	
30			1	1	1134-2541-01	Seat	
40	2	2	2	2	1134-2961-01	Seat adapter	
41	2	2	2	2	1134-1711-01	Knob	
42	2	2	2	2	9699-0062-02	Flat washer	
43	4	4	4	4	9988-3616-16	Screw	
44	2	2	2	2	9898-0820-16	Screw	

test