



## Section: PARK HST DRIVE PEDAL CRUISE CONTROL

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1358	1458	1818			
	1443	1446	1448			
2	1	1	1	1134-3706-01	Pedal	
3		1	1	1134-2849-01	Rubber hose	L = 30 mm
3	1			1134-2849-03	Rubber hose	L = 60 mm
4	2	2	2	1134-2780-01	Bearing	
5	2	2	2	1134-2700-01	Bracket	
6	2	2	2	9959-0820-16	Screw	
7	5	7	7	9739-0831-22	Nut	
8	1	1	1	1134-3704-01	Lever	
9	2	2	2	9997-0520-16	Screw	
10	2	2	2	9739-0531-22	Nut	
11	2	2	2	9699-0087-02	Flat washer	
12		1	1	1134-2766-02	Speed control wire	
12	1			1134-2766-03	Speed control wire	
14		1	1	9595-0235-00	Locating pin	
17	1			1134-2030-11	Clutch cable	
17		1	1	1134-3584-01	Brake/clutch wire	
18	1			1134-2991-01	Eye bolt	
19	1	1	1	1131-1506-00	Spring	
20	1			9747-0531-02	Nut	
23	1	1	1	1134-3450-01	Brake pedal (L. H.)	
24	1	1	1	1134-9024-01	.Bearing	Sats 4 st/kit of 4
25	1	1	1	1134-0269-00	Pedal rubber	
35	1	1	1	1134-0266-00	Attaching clamp	
37	2	3	3	9997-0520-16	Screw	
50		2	2	9959-0816-16	Screw	
52	1	1	1	9570-0001-00	Elbow link	
81	1	1	1	9997-0870-16	Screw	
103	1	1	1	9959-0816-16	Screw	
108	6	5	5	9739-0531-22	Nut	
113	1	1	1	1134-0267-00	Clamp plate	
117		1	1	1134-2859-01	Magneto assy	
118		1	1	1134-2858-01	Spring	
119		1	1	1134-2862-01	Lever	
121		1	1	1134-2866-02	Plate	
122		1		1134-2857-01	Switch	Farthåll/cruise con
123		1		1134-3640-01	Harness	
124		1	1	1134-2871-01	Relay	
125		1		1134-2902-01	Symbol plate-green	