



Section: KANZAKI TRANSAXLE K46G CONTROL SHAFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

K46G

1	1	1139-1274-01	Control shaft			
2	1	1139-1190-01	Fulcrum			
3	1	1139-1252-01	Spring			
4	1	1139-1253-01	Control arm			
5	1	1139-1254-01	Control lever			
6	1	1139-1250-01	Jerky plate			
7	1	1139-1102-01	Washer			
8	1	1139-1283-01	Pin			
9	1	1139-1284-01	Pin			
10	1	1139-1285-01	Pin			
11	2	1139-1115-01	O-ring			
12	1	1139-1127-01	Nut			

test