



Section: KANZAKI TRANSAXLE K62E-K66B CONTROL SHAFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

K62E K66B

1	1	1	1139-1165-01	Seal		
2	1	1	1139-1191-01	Control shaft assy	Inkl. pos 3 - 10	
8	1	1	1139-1278-01	.Ring		
11	1	1	1139-1190-01	Fulcrum		
12	1	1	1139-1102-01	Washer		
13	2	2	1139-1115-01	O-ring		
14	1	1	1139-1127-01	Nut		

test