



Section: COLLECTOR 48S DAKOTA 48 SLS45 TRANSMISSION REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

5288
-27 5688

1	1	1	1111-2808-01		Rear axle	
2	2	2	1111-2814-01		Bushing	
3	4	4	9947-0616-16		Screw	
4	5	5	9838-9522-12		Screw	
5	1	1	1111-2798-01		Height adj.quadrant	
6	1	1	1111-2816-01		Height adj.lever	
7	1	1	1111-2817-01		Lever knob	
8	2	2	9943-0612-16		Screw	
10	2	2	1111-2665-01		Wheel assy	
11	1	1	1111-9047-01		.Ball bearing kit	
12	2	2	1111-1184-01		..Bearing cone	
15	2	2	9699-0100-02		Washer	
16	2	2	9943-0612-16		Screw	
17	2	2	1111-3085-01		Hub cap-yellow	
20	2	2	1111-3060-01		Spring	
22	2	2	1111-2561-01		Cover plate	
23	1	1	1111-2915-01		Engine belt pulley	
24	1	1	9910-0612-16		Set screw	
25	1	1	1111-9061-01		V-belt	
26	1	1	1111-3046-01		Transmission	
27	1	1	1111-3047-01		Belt pulley	
28	1	1	9595-0235-00		Locating pin	
30	1	1	1111-2822-01		Tension spring	
31	2	2	1111-2382-01		Pin	
32	2	2	1111-3256-01		Drive key	
33	2	2	9404-0083-00		Seal ring	
36	4	4	9695-0013-00		Washer	
37	2	2	1111-2829-01		Lock washer	
38	2	2	1111-3075-01		Pinion plastic whee	
39	2	2	1111-2830-01		Support washer	
41	2	2	9652-0010-04		Snap ring	
45	1	1	1111-3249-01		Clutch cable	
47	1	1	1117-1374-01		Control handle	
48	1	1	1111-2969-01		Cable attachment	
49	1	1	9948-0640-16		Screw	
50	1	1	9747-0631-02		Lock nut	
53		1	1111-2794-04		Cover-red	
53	1		1111-2794-01		Cover-yellow	