



test

## Section: 928-928T-1333 DRIVE TRAIN

| Pos. | Quantity |      | Spare part No | Description  | Kit | Notes               | New      |
|------|----------|------|---------------|--------------|-----|---------------------|----------|
|      | 2837     | 2838 | 2861          |              |     |                     |          |
| 190  | 1        | 1    | 1             | 1812-1543-01 |     | Clutch lever        |          |
| 191  | 2        | 2    | 2             | 1812-0328-01 |     | Bushing             |          |
| 192  | 2        | 2    | 2             | 1812-1480-01 |     | Retaining ring      |          |
| 193  | 1        | 1    | 1             | 1812-0364-01 |     | Spring              |          |
| 195  | 1        | 1    | 1             | 1812-1217-01 |     | Traction spring lev |          |
| 196  | 1        | 1    | 1             | 9988-3516-16 |     | Screw               |          |
| 198  | 1        | 1    | 1             | 1812-0812-01 |     | Locking nut         |          |
| 210  | 1        | 1    | 1             | 1812-1269-01 |     | Friction disc       |          |
| 211  | 1        | 1    | 1             | 1812-1425-01 |     | Grease zerk         |          |
| 215  | 1        | 1    | 1             | 1812-1262-01 |     | Traction hex shaft  |          |
| 216  | 1        | 1    | 1             | 1812-0450-01 |     | Bearing             |          |
| 217  | 2        | 2    | 2             | 9699-0038-02 |     | Flat washer         |          |
| 221  | 1        | 1    | 1             | 1812-0402-01 |     | Retaining ring      |          |
| 222  | 2        | 2    | 2             | 1812-1238-01 |     | Washer              |          |
| 223  | 2        | 2    | 2             | 1812-1383-01 |     | Ball bearing        |          |
| 224  | 1        | 1    | 1             | 1812-1609-01 |     | Key                 |          |
| 225  | 1        | 1    | 1             | 1812-1236-01 |     | Traction pulley     |          |
| 226  | 1        | 1    | 1             | 1812-1237-01 |     | Wave washer         |          |
| 227  | 1        | 1    | 1             | 1812-1190-01 |     | Flat washer         |          |
| 228  | 1        | 1    | 1             | 9683-0025-02 |     | Lock washer         |          |
| 229  | 1        | 1    | 1             | 1812-1588-01 |     | Screw               |          |
| 230  | 1        | 1    | 1             | 1812-1200-01 |     | Bearing retainer    |          |
| 231  | 2        | 2    | 2             | 1812-0385-01 |     | Screw               |          |
| 233  | 1        | 1    | 1             | 1812-1207-01 |     | Ball bearing        |          |
| 235  | 1        | 1    | 1             | 1812-1204-01 |     | Washer              |          |
| 240  | 1        | 1    | 1             | 1812-1312-01 |     | Hex shaft           |          |
| 243  | 1        | 1    | 1             | 1812-1164-01 |     | Retainer ring       |          |
| 244  | 2        | 2    | 2             | 9699-0038-02 |     | Flat washer         |          |
| 245  | 1        | 1    | 1             | 1812-1313-01 |     | Trunion bearing     |          |
| 246  | 1        | 1    | 1             | 1812-9002-01 |     | Friction disc       |          |
| 247  | 3        | 3    | 3             | 9988-3516-16 |     | Screw               |          |
| 249  | 3        | 3    | 3             | 9795-3531-02 |     | Nut                 |          |
| 250  | 1        | 1    | 1             | 1812-1204-01 |     | Washer              |          |
| 255  | 1        | 1    | 1             | 1812-1200-01 |     | Bearing retainer    |          |
| 256  | 2        | 2    | 2             | 1812-0385-01 |     | Screw               |          |
| 258  | 1        | 1    | 1             | 1812-1207-01 |     | Ball bearing        |          |
| 270  | 1        | 1    | 1             | 1812-1200-01 |     | Bearing retainer    |          |
| 271  | 2        | 2    | 2             | 1812-0385-01 |     | Screw               |          |
| 272  | 1        | 1    | 1             | 1812-1207-01 |     | Ball bearing        |          |
| 275  | 1        | 1    |               | 1812-1522-01 |     | Jack shaft          | 36T & 8T |
| 275  |          |      | 1             | 1812-1540-01 |     | Jack shaft          | 36T & 7T |
| 276  | 1        | 1    | 1             | 1812-1200-01 |     | Bearing retainer    |          |
| 277  | 2        | 2    | 2             | 1812-0385-01 |     | Screw               |          |
| 278  | 1        | 1    | 1             | 1812-1209-01 |     | Chain               |          |
| 279  | 1        | 1    | 1             | 1812-1207-01 |     | Ball bearing        |          |